

APPENDIX Q

ICC INTERNATIONAL RESIDENTIAL CODE ELECTRICAL PROVISIONS/NATIONAL ELECTRICAL CODE CROSS-REFERENCE

This table is a cross-reference of the *International Residential Code*, Chapters 33 through 42, and the 2005 *National Electrical Code* (NFPA 70-2005).

International Residential Code	National Electrical Code
CHAPTER 33	GENERAL REQUIREMENTS
SECTION E3301	GENERAL
E3301.1	Applicability None
E3301.2	Scope 90.2
E3301.3	Not covered 90.2
E3301.4	Additions and alterations None
SECTION E3302	BUILDING STRUCTURE PROTECTION
E3302.1	Drilling and notching None
E3302.2	Penetrations of fire-resistance-rated assemblies 300.21
E3302.3	Penetrations of firestops and draftstops 300.21
SECTION E3303	INSPECTION AND APPROVAL
E3303.1	Approval 110.2
E3303.2	Inspection required None
E3303.3	Listing and labeling 110.3
SECTION E3304	GENERAL EQUIPMENT REQUIREMENTS
E3304.1	Voltages 110.4
E3304.2	Interrupting rating 110.9
E3304.3	Circuit characteristics 110.10
E3304.4	Protection of equipment 110.11
E3304.5	Unused openings 110.12(A)
E3304.6	Integrity of electrical equipment 110.12(C)
E3304.7	Mounting 110.13(A)
E3304.8	Energized parts guarded against accidental contact 110.27(A)
E3304.9	Prevent physical damage 110.27(B)
E3304.10	Equipment identification 110.21
E3304.11	Identification of disconnecting means 110.22
SECTION E3305	EQUIPMENT LOCATION AND CLEARANCES
E3305.1	Working space and clearances 110.26
Figure E3305.1	Working space and clearances 110.26(A)
	Footnote 1 110.26(F)(1)(a)
	Footnote 2 110.26(A)(3) and 110.26(E)
	Footnote 3 110.26(B)
	Footnote 4 230.70(A), 240.24(D) and 240.24(E)
	Footnote 5 110.26(D)
E3305.2	Working clearances for energized equipment and panelboards 110.26(A)(1), (2), & (3)
E3305.3	Clearances over panelboards 110.26(F)(1)(a)
E3305.4	Location of clear spaces 110.26(B), 230.70(A) and 240.24(D) & (E)
E3305.5	Access and entrance to working space 110.26(C)(1)
E3305.6	Illumination 110.26(D)
E3305.7	Headroom 110.26(E)
SECTION E3306	ELECTRICAL CONDUCTORS AND CONNECTIONS
E3306.1	General Articles 110, 300 and 310

APPENDIX Q

E3306.2	Conductor material	110.5
E3306.3	Minimum size of conductors	310.5
E3306.4	Stranded conductors	310.3
E3306.5	Individual conductor insulation	310.2(A) and 310.8
E3306.6	Conductors in parallel	310.4
E3306.7	Conductors of the same circuit	300.3(B)
E3306.8	Aluminum and copper connections	110.14
E3306.9	Terminals	110.14(A)
E3306.10	Splices	110.14(B)
E3306.10.1	Continuity	300.13(A)
	Exception	300.13(A)
E3306.10.2	Device connections	250.148 and 300.13(B)
E3306.10.3	Length of conductor for splice or termination	300.14
SECTION E3307	CONDUCTOR IDENTIFICATION	
E3307.1	Grounded conductors	200.6(A), 200.6(B) and 310.12(A)
E3307.2	Equipment grounding conductors	250.119 and 310.12(B)
E3307.3	Ungrounded conductors	310.12(C), 310.12(C), Exception and 200.7(C)(1) & (C)(2)
E3307.4	Identification of terminals	200.10
E3307.4.1	Device terminals	200.10(A)
E3307.4.2	Receptacles, plugs, and connectors	200.10(B)
CHAPTER 34	ELECTRICAL DEFINITIONS	
SECTION 3401	GENERAL	Article 100, Definitions
CHAPTER 35	SERVICES	
SECTION E3501	GENERAL SERVICES	
E3501.1	Scope	230.1
E3501.2	Number of services	230.2
E3501.3	One building or other structure not to be supplied through another	230.3
E3501.4	Other conductors in raceway or cable	230.7
E3501.5	Raceway seal	230.8
E3501.6	Service disconnect required	230.70
E3501.6.1	Marking of service equipment and disconnects	230.66 and 230.70(B)
E3501.6.2	Service disconnect location	230.70 and 230.72(C)
E3501.7	Maximum number of disconnects	230.71(A)
SECTION E3502	SERVICE SIZE AND RATING	
E3502.1	Rating of ungrounded conductors	230.79(C) and (D)
E3502.2	Service load	220.82(A)
E3502.2.1	Services under 100 amperes	None
Table E3502.2	Minimum service load calculation	220.82 (B) and (C)
E3502.3	Rating of service disconnect	230.79 & 230.80
E3502.4	Voltage rating	220.82(a)
SECTION E3503	SERVICE, FEEDER AND GROUNDING ELECTRODE CONDUCTOR SIZING	
E3503.1	Grounded and ungrounded service conductor size	310.15(B)(6)
Table E3503.1	Service conductor and grounding electrode conductor sizing. Table 310.15(B)(6) and Table 250.66	
	Footnote 1	250.64(E)
	Footnote 2	250.64(B)
	Footnote 3	250.64(B)
	Footnote 4	250.66(A) and (B)
E3503.2	Ungrounded service conductors for accessory buildings and structures	230.79(D)
	Exception 1	and 230.79(A)
	Exception 2	and 230.79(B)
E3503.3	Overload protection	230.90
E3503.3.1	Ungrounded conductor	230.90(A)

	Exception	230.90(A), Exception No. 3
E3503.3.2	Not in grounded conductor	230.90(B)
E3503.3.3	Location	230.91
E3503.4	Grounding electrode conductor size	250.66
E3503.5	Temperature limitations	110.14(C)(1)
SECTION E3504	OVERHEAD SERVICE-DROP AND SERVICE CONDUCTOR INSTALLATION	
E3504.1	Clearances on buildings	230.9
Figure E3504.1	Clearances from building openings	230.9
E3504.2	Vertical clearances	230.24
E3504.2.1	Above roofs	230.24(A)
	Exception 1	230.24(A), Exception No. 1
	Exception 2	230.24(A), Exception No. 2
	Exception 3	230.24(A), Exception No. 3
	Exception 4	230.24(A), Exception No. 4
Figure E3504.2.1	Clearances from roofs	230.24
E3504.2.2	Vertical clearance from grade	230.24(B)
	Item 1	230.24(B)(1)
	Item 2	230.24(B)(2)
	Item 3	230.24(B)(4)
E3504.3	Point of attachment	230.26
E3504.4	Means of attachment	230.27
E3504.5	Service masts as supports	230.28
E3504.6	Supports over buildings	230.29
SECTION E3505	SERVICE-ENTRANCE CONDUCTORS	
E3505.1	Insulation of service-entrance conductors	230.41
	Exception 1	230.41, Exception
	Exception 2	230.41, Exception
E3505.2	Wiring methods for services	230.43
E3505.3	Spliced conductors	230.46
E3505.4	Protection against physical damage	230.49
E3505.5	Protection of service cables against damage	230.50(A)
E3505.6	Direct sunlight exposure	310.8(D)
E3505.7	Mounting supports	230.51
E3505.8	Raceways to drain	230.53
E3505.9	Overhead service locations	230.54
E3505.9.1	Rain-tight service head	230.54(A)
E3505.9.2	Service cable, service head or gooseneck	230.54(B)
E3505.9.3	Service head location	230.54(C)
	Exception	230.54(C), Exception
E3505.9.4	Separately bushed openings	230.54(E)
E3505.9.5	Drip loops	230.54(F)
E3505.9.6	Conductor arrangement	230.54(G)
E3505.9.7	Secured	230.54(D)
SECTION E3506	SERVICE EQUIPMENT—GENERAL	
E3506.1	Service equipment enclosures	230.62
E3506.2	Working space	110.26
E3506.3	Available short-circuit current	None
E3506.4	Marking	230.66
SECTION E3507	SYSTEM GROUNDING	
E3507.1	System service ground	250.20(B)(1) and 250.24(A)
E3507.2	Location of grounding electrode conductor connection	250.24(A)(1) and (A)(5)
E3507.3	Buildings or structures supplied by feeder(s) or branch circuit(s)	250.32(A)
	Exception	250.32(A), Exception
E3507.3.1	Equipment grounding conductor	250.32(B)(1) and Table 250.122

E3507.3.2	Grounded conductor	250.32(B)(2)
E3507.4	Grounding electrode conductor	250.24(D)
E3507.5	Main bonding jumper	250.28
E3507.6	Common grounding electrode	250.58

SECTION E3508 GROUNDING ELECTRODE SYSTEM

E3508.1	Grounding electrode system	250.50
E3508.1	Exception	250.50 Exception
E3508.1.1	Metal underground water pipe	250.52(A)(1)
E3508.1.1.1	Installation	250.53(D) and 250.53(E)
E3508.1.2	Concrete-encased electrode	250.502(A)(3)
E3508.1.3	Ground Rings	250.52(A)(4), 250.53(F)
E3508.1.4	Rod and pipe electrodes	250.52(A)(5)
E3508.1.4.1	Installation	250.53(G)
E3508.1.5	Plate electrodes	250.52(A)(6) and 250.53(H)
E3508.2	Bonding Jumper	250.53(C)
E3508.3	Rod, pipe and plate electrode requirements	250.53(A) and (G)
E3508.4	Resistance of rod, pipe and plate electrodes	250.56
E3508.5	Aluminum Electrodes	250.52(B)(2)
E3508.6	Metal underground gas piping system	250.52(B)(1)

SECTION E3509 BONDING

E3509.1	General	250.90
E3509.2	Bonding of service equipment	250.92(A)
E3509.3	Bonding to other systems	250.94
E3509.4	Method of bonding at the service	250.92(B)
E3509.4.1	Grounded service conductor	250.92(B)(1)
E3509.4.2	Threaded connections	250.92(B)(2)
E3509.4.3	Threadless couplings and connectors	250.92(B)(3)
E3509.4.4	Other devices	250.92(B)(4)
E3509.5	Sizing bonding jumper on supply side of service and main bonding jumper	250.102(C)
E3509.6	Metal water piping bonding	250.104(A)
E3509.7	Bonding other metal piping	250.104(B)

SECTION E3510 GROUNDING ELECTRODE CONDUCTORS

E3510.1	Continuous	250.64(C) and (E)
E3510.2	Securing and protection against physical damage	250.64(A) and (B)
E3510.3	Enclosures for grounding electrode conductors	250.64(E)

SECTION E3511 GROUNDING ELECTRODE CONDUCTOR CONNECTION TO GROUNDING ELECTRODES

E3511.1	Methods of grounding connection to electrodes	250.70
E3511.2	Accessibility	250.68(A)
E3511.3	Effective grounding path	250.68(B)
E3511.4	Protection of ground clamps and fittings	250.10
E3511.5	Clean surfaces	250.12

CHAPTER 36 BRANCH CIRCUIT AND FEEDER REQUIREMENTS

SECTION E3601 GENERAL

E3601.1	Scope	None
E3601.2	Branch-circuit and feeder ampacity	210.19(A) and 215.2(A)(1)
E3601.3	Selection of ampacity	310.15(A)(2)
E3601.4	Multioutlet branch circuits	210.19(A)(2)
E3601.5	Multiwire branch circuits	210.4

SECTION E3602 BRANCH CIRCUIT RATINGS

E3602.1	Branch-circuit voltage limitations	210.6(A) and (B)
E3602.2	Branch-circuit ampere rating	210.3

E3602.3	Fifteen- and 20-ampere branch circuits	210.23(A)
E3602.4	Thirty-ampere branch circuits	210.23(B)
E3602.5	Branch circuits serving multiple loads or outlets	210.23(A)
E3602.6	Branch circuits serving a single motor	430.22(A)
E3602.7	Branch circuits serving motor-operated and combination loads	220.4(A)
E3602.8	Branch-circuit inductive lighting loads	220.4(B)
E3602.9	Branch-circuit load for ranges and cooking appliances	Table 220.19, Note 4
E3602.9.1	Minimum branch circuit for ranges	210.19(A)(3)
E3602.10	Branch circuits serving heating loads	422.13 and 424.3(A)
E3602.11	Branch circuits for air-conditioning and heat pump equipment	440.35, 440.4(B) and 440.62(A)
E3602.12	Branch circuits serving room air conditioners	440.62(A)
E3602.12.1	Where no other loads are supplied.	440.62(B)
E3602.12.2	Where lighting units or other appliances are also supplied	440.62(C)
E3602.13	Branch-circuit requirement—summary	210.24 and 210.25
Table E3602.13	Branch-circuit requirement—summary	Table 210.24
SECTION E3603 REQUIRED BRANCH CIRCUITS		
E3603.1	Branch circuits for heating	422.12 and 422.12 Exception
E3603.2	Kitchen and dining area receptacles	210.52 (B)(1)
E3603.3	Laundry circuit	210.23(A) Exception and 210.11(C)(2)
E3603.4	Bathroom branch circuits.	210.11(C)(3)
E3603.5	Number of branch circuits	210.11(A)
E3603.6	Branch-circuit load proportioning	210.11(B)
SECTION E3604 FEEDER REQUIREMENTS		
E3604.1	Conductor size	Table 310.15(B)(6), Sections 215.2 (A)(3), (A)(4) and 220.10(A)
E3604.2	Minimum feeder conductor size	215.2(A)(2)
E3604.3	Feeder loads	Table 220.11
Table E3604.3(1)	Feeder load calculation	Table 220.11, Table 220.30(C), Sections 220.14, 220.15, 220.17, 220.18 and 220.19
Table E3604.3(2)	Demand loads for electric ranges, wall-mounted ovens, counter-mounted cooking units and other cooking appliances over 1 ³ / ₄ kVA rating	Table 220.19
E3604.4	Feeder neutral load	220.22
E3604.5	Lighting and convenience receptacle load	220.3(A), Table 220.3(A)
E3604.6	Ampacity and computed loads.	220.10
E3604.7	Feeder and branch-circuit conductors	240.21(A)
SECTION E3605 CONDUCTOR SIZING AND OVERCURRENT PROTECTION		
E3605.1	General	310.15(A)
Table E3605.1	Allowable ampacities	Tables 310.16 and 240.4 D
E3605.2	Correction factors for ambient temperatures	Table 310.16
Table E3605.2	Ambient temperature correction factors	Table 310.16, Correction factors
E3605.3	Adjustment factor for conductor proximity	310.15(B)(2)(a)
Table E3605.3	Conductor proximity adjustment factors	Table 310.15(B)(2)(a)
E3605.4	Temperature limitations	110.14(C)
E3605.4.1	Conductors rated 60°C.	110.14(C)(1)(a)
E3605.4.2	Conductors rated 75°C.	110.14(C)(1)(b)
E3605.4.3	Separately installed pressure connectors	110.14(C)(2)
E3605.4.4	Conductors of type NM cable	334.80 and 334.112
E3605.5	Overcurrent protection required	Table 310.15(B)(6), Sections 240.4, 240.5, 240.21
E3605.5.1	Cords	240.5
E3605.5.2	Overcurrent devices of the next higher size	240.4(B)
E3605.5.3	Small conductors.	240.4(D)
E3605.5.4	Air conditioning and heat pump equipment	240.4(G)
E3605.6	Fuses and fixed trip circuit breakers	Section 240.6
E3605.7	Location of overcurrent devices in or on premises	240.24(A),(C),(D),(E)
E3605.8	Ready access for occupants	Section 240.24(B)

APPENDIX Q

E3605.9 Enclosures for overcurrent devices Section 240.30 (A) and (B)

SECTION E3606 PANELBOARDS

E3606.1 Panelboard rating 408.13
E3606.2 Panelboard circuit identification 408.4
E3606.3 Panelboard overcurrent protection 408.16(A)
E3606.4 Grounded conductor terminations 408.41
E3606.5 Back-fed devices 408.36(F)

CHAPTER 37 WIRING METHODS

SECTION E3701 GENERAL REQUIREMENTS

E3701.1 Scope Section 300.1
E3701.2 Allowable wiring methods Sections 110.8 and 300.3(A)
Table E3701.2 Allowable wiring methods None
E3701.3 Circuit conductors 300.3(B)
E3701.4 Wiring method applications Chapter 3 and Section 300.2
Table E3701.4 Allowable applications for wiring methods Chapter 3 and Section 300.2

SECTION E3702 ABOVE-GROUND INSTALLATION REQUIREMENTS

E3702.1 Installation and support requirements Chapter 3
Table E3702.1 General installation and support requirements for wiring methods Chapter 3
E3702.2 Cables in accessible attics 320.23 and 334.23
E3702.2.1 Across structural members 320.23(A) and 334.23
E3702.2.2 Cable installed through or parallel to
framing members 320.17, 320.23(A), 334.17, 334.23 and 300.4(B)
E3702.3 Exposed cable 320.15 and 334.15
E3702.3.1 Surface installation 334.15(A)
E3702.3.2 Protection from physical damage 334.15(B)
E3702.3.3 Locations exposed to direct sunlight 310.8(D)
E3702.4 In unfinished basements 334.15(C)
E3702.5 Bends 320.24 and 334.24
E3702.6 Raceways exposed to different temperatures Section 300.7(A)

SECTION E3703 UNDERGROUND INSTALLATION REQUIREMENTS

E3703.1 Minimum cover requirements 300.5(A)
Table E3703.1 Minimum cover requirements, burial in inches Table 300.5
E3703.2 Warning ribbon 300.5(D)(3)
E3703.3 Protection from damage 300.5(D)
E3703.4 Splices and taps 300.5(E)
E3703.5 Backfill 300.5(F)
E3703.6 Raceway seals 300.5(G)
E3703.7 Bushing 300.5(H)
E3703.8 Single conductors 300.5(I)
E3703.9 Ground movement Section 300.5(J)

CHAPTER 38 POWER AND LIGHTING DISTRIBUTION

SECTION E3801 RECEPTACLE OUTLETS

E3801.1 General 210.50 and 210.52
E3801.2 General-use receptacle distribution 210.52(A)
E3801.2.1 Spacing 210.52(A)(1)
E3802.2.2 Wall space 210.52(A)(2)
E3801.2.3 Floor receptacles 210.52(3)
E3801.3 Small appliance receptacles 210.52(B)(1)
E3801.3.1 Other outlets prohibited 210.52(B)(2)
E3801.3.2 Limitations 210.52(B)(3)
E3801.4 Countertop receptacles 210.52(C)
E3801.4.1 Wall counter space 210.52(C)(1)

E3801.4.2	Island counter spaces	210.52(C)(2)
E3801.4.3	Peninsular counter space	210.52(C)(3)
E3801.4.4	Separate spaces	210.52(C)(4)
E3801.4.5	Receptacle outlet location	210.52(C)(5)
E3801.5	Appliance outlets	210.50(C)
E3801.6	Bathroom	210.52(D)
E3801.7	Outdoor outlets	210.52(E)
E3801.8	Laundry areas	210.52(F)
E3801.9	Basements and garages	210.52(G)
E3801.10	Hallways	210.52(H)
E3801.11	HVAC outlet	210.63

SECTION E3802 GROUND-FAULT AND ARC-FAULT CIRCUIT-INTERRUPTER PROTECTION

E3802.1	Bathroom receptacles	210.8(A)(1)
E3802.2	Garage and accessory building receptacles	210.8(A)(2)
E3802.3	Outdoor receptacles	210.8(A)(3)
E3802.4	Crawl space receptacles	210.8(A)(4)
E3802.5	Unfinished basement receptacles	210.8(A)(5)
E3802.6	Kitchen receptacles	210.8(A)(6)
E3802.7	Laundry, utility and wet bar sink receptacles	210.8(A)(7)
E3802.8	Boathouse receptacles	210.8(A)(8)
E3802.9	Boat hoists	210.8(C)
E3802.10	Electrically heated floors	424.44(G)
E3802.11	Exempt receptacles	210.8(A)(2)
E3802.12	Bedroom outlets	210.12

SECTION E3803 LIGHTING OUTLETS

E3803.1	General	210.70(A)
E3803.2	Habitable rooms	210.70(A)(1)
E3803.3	Additional locations	210.70(A)(2)
E3803.4	Storage or equipment spaces	210.70(A)(3)

SECTION E3804 GENERAL INSTALLATION REQUIREMENTS

E3804.1	Electrical continuity of metal raceways and enclosures	300.10
E3804.2	Mechanical continuity—raceways and cables	300.12
E3804.3	Securing and supporting	300.11(A)
E3804.3.1	Prohibited means of support	300.11(C)
E3804.4	Raceways as means of support	300.11(B)
E3804.5	Raceway installations	300.18
E3804.6	Conduit and tubing fill	300.17 and Chapter 9, Table 1
Tables E3804.6(1)- E3804.6(10)	Maximum number of conductors in conduit or tubing	300.17 and Chapter 9, Table 1, Note 1
E3804.7	Air handling—stud cavity and joist spaces	Section 300.22(C), Exception

CHAPTER E3805 BOXES, CONDUIT BODIES, AND FITTINGS

E3805.1	Box, conduit body or fitting—where required	300.15
E3805.1.1	Equipment	300.15(B)
E3805.1.2	Protection	300.15(C)
E3805.1.3	Integral enclosure	300.15(E)
E3805.1.4	Fitting	300.15(F)
E3805.1.5	Buried conductors	300.15(G)
E3805.1.6	Luminaires	300.15(J)
E3805.1.7	Closed loop	300.15(M)
E3805.2	Metal boxes	314.4
E3805.3	Nonmetallic boxes	314.3
E3805.3.1	Nonmetallic-sheathed cable and nonmetallic boxes	314.17(C)
E3805.3.2	Securing to box	314.17(B) and (C)

APPENDIX Q

E3805.3.3	Conductor rating	314.17(C)
E3805.4	Minimum depth of outlet boxes	314.24
E3805.5	Boxes enclosing flush-mounted devices	314.19
E3805.6	Boxes at luminaire (lighting fixture) outlets	314.27(A)
E3805.7	Maximum luminaire (fixture) weight	314.27(B)
E3805.8	Floor boxes	314.27(C)
E3805.9	Boxes at fan outlets	314.27(D)
E3805.10	Conduit bodies, junction, pull and outlet boxes to be accessible	314.29
E3805.11	Damp or wet locations	314.2
E3805.12	Number of conductors in outlet, device, and junction boxes and conduit boxes	314.16
E3805.12.1	Box volume calculations	314.16(A)
Table E3805.12.1	Maximum number of conductors in metal boxes	Table 314.16
E3805.12.1.1	Standard boxes	314.16(A)(1)
E3805.12.1.2	Other boxes	314.16(A)(2)
E3805.12.2	Box fill calculations	314.16(B)
E3805.12.2.1	Conductor fill	314.16(B)(1) and Table 314.16
Table E3805.12.2.1	Volume allowance required per conductor	Table 314.16
E3805.12.2.2	Clamp fill	314.16(B)(2)
E3805.12.2.3	Support fittings fill	314.16(B)(3)
E3805.12.2.4	Device or equipment fill	314.16(B)(4)
E3805.12.2.5	Equipment grounding conductor fill	314.16(B)(5)
E3805.12.3	Conduit bodies	314.16(C)(1)
E3805.12.3.1	Splices, taps or devices	314.16(C)(2)

SECTION E3806 INSTALLATION OF BOXES, CONDUIT BODIES AND FITTINGS

E3806.1	Conductors entering boxes, conduit bodies or fittings	314.17
E3806.1.1	Insulated fittings	300.4(F)
E3806.2	Openings	314.17(A)
E3806.3	Metal boxes, conduit bodies and fittings	314.17, 314.17(B)
E3806.4	Unused openings	110.12(A)
E3806.5	In wall or ceiling	314.20
E3806.6	Plaster, gypsum board and plasterboard	314.21
E3806.7	Exposed surface extensions	314.22
E3806.8	Supports	314.23
E3806.8.1	Surface mounting	314.23(A)
E3806.8.2	Structural mounting	314.23(B)
E3806.8.2.1	Nails	314.23(B)(1)
E3806.8.2.2	Braces	314.23(B)(2)
E3806.8.3	Mounting in finished surfaces	314.23(C)
E3806.8.4	Raceway supported enclosures without devices or fixtures	314.23(E)
E3806.8.5	Raceway supported enclosures with devices or fixtures	314.23(F)
E3806.8.6	Enclosures in concrete or masonry	314.23(G)
E3806.9	Covers and canopies	314.25
E3806.10	Metal covers and plates	314.25(A)
E3806.11	Exposed combustible finish	314.25(B)

SECTION E3807 CABINETS AND PANELBOARDS

E3807.1	Enclosures for switches or overcurrent devices	312.8
E3807.2	Damp or wet locations	312.2(A)
E3807.3	Position in wall	312.3
E3807.4	Repairing plaster, drywall and plasterboard	312.4
E3807.5	Unused openings	110.12(A), 408.7
E3807.6	Conductors entering cabinets	300.4(F) and 312.5(B)
E3807.7	Openings to be closed	312.5(A)
E3807.8	Cables	312.5(C)

SECTION E3808	GROUNDING	
E3808.1	Metal enclosures	250.86
E3808.2	Equipment fastened in place or connected by permanent wiring methods (fixed)	250.110(1), (2), and (3)
E3808.3	Specific equipment fastened in place or connected by permanent wiring methods	250.112(J), (L), and (M)
E3808.4	Performance of fault current path	250.4(A)(5)
E3808.5	Earth as a grounding conductor	250.4(A)(5)
E3808.6	Load-side neutral	250.24(A)(5)
E3808.7	Load-side equipment	250.142 (B)
E3808.8	Types of equipment grounding conductors	250.118
E3808.8.1	Flexible metal conduit	250.118(5)
E3808.8.2	Liquid-tight flexible metal conduit	250.118(6)
E3808.8.3	Nonmetallic sheathed cable (Type NM)	334.108
E3808.9	Equipment fastened in place or connected by permanent wiring methods	250.134
E3808.10	Methods of equipment grounding	250 Part (VII)
E3808.11	Equipment grounding conductor installation	250.120
E3808.12	Equipment grounding conductor size	250.122(A) and (B)
Table E3808.12	Equipment grounding conductor sizing	Table 250.122
E3808.12.1	Multiple circuits	250.122(C)
E3808.13	Continuity and attachment of equipment grounding conductors to boxes	250.148
E3808.14	Connecting receptacle grounding terminal to box	250.146(A), (B), and (C)
E3808.15	Metal boxes	250.8, 250.148(C)
E3808.16	Nonmetallic boxes	250.148(D)
E3808.17	Clean surfaces	250.12
E3808.18	Bonding other enclosures	250.96(A)
E3808.19	Size of equipment bonding jumper on load side of service	250.102(D)
E3808.20	Installation—equipment bonding jumper	250.102(E)
SECTION E3809	FLEXIBLE CORDS	
E3809.1	Where permitted	400.7 and 400.8
E3809.2	Loading and protection	240.4, 240.5(A), 240.5(B)(1), 400.5, and 400.13
Table E3809.2	Maximum ampere load for flexible cords	Table 400.5(A)
E3809.3	Splices	400.9
E3809.4	Attachment plugs	400.7(B)
CHAPTER 39	DEVICES AND LIGHTING FIXTURES	
SECTION E3901	SWITCHES	
E3901.1	Rating and application of snap switches	404.14(A)
E3901.2	CO/ALR snap switches	404.14(C)
E3901.3	Indicating	404.7
E3901.4	Time switches and similar devices	404.5
E3901.5	Grounding of enclosures	404.12
E3901.6	Access	404.8(A)
E3901.7	Wet locations	404.4
E3901.8	Grounded conductors	404.2(B)
E3901.9	Switch connections	404.2(A)
E3901.10	Box mounted	404.10(B)
E3901.11	Snap switch faceplates	404.9(A)
E3901.11.1	Faceplate grounding	404.9(B)
E3901.12	Dimmer switches	404.14(E)
SECTION E3902	RECEPTACLES	
E3902.1	Rating and type	406.2(A)(B)
E3902.1.1	Single receptacle	210.21(B)(1)
E3902.1.2	Two or more receptacles	210.21(B)(3)
Table E3902.1.2	Receptacle ratings for various size multioutlet circuits	Table 210.21(B)(3)

E3902.2	Grounding type	406.3(A)
E3902.3	CO/ALR receptacles	406.2(C)
E3902.4	Faceplates	406.5(B)
E3902.5	Position of receptacle faces	406.4(D), and 406.5
E3902.6	Receptacles mounted in boxes	406.4(A), and 406.4(B)
E3902.7	Receptacles mounted on covers	406.4(C)
E3902.8	Damp locations	406.8(A)
E3902.9	15- and 20-ampere receptacles in wet locations.	406.8(B)(1)
E3902.10	Other receptacles in wet locations.	406.8(B)(2)
E3902.11	Bathtub and shower space.	406.8(C)
E3902.12	Flush mounting with faceplate	406.8(E)

SECTION E3903 LUMINAIRES

E3903.1	Energized parts	410.3
E3903.2	Luminaires near combustible material	410.5
E3903.3	Exposed conductive parts	410.18(A)
E3903.4	Screw-shell type	410.47
E3903.5	Recessed incandescent luminaires	410.65(C)
E3903.6	Thermal protection	410.73(E)
E3903.7	High-intensity discharge luminaires	410.73(F)
E3903.8	Wet or damp locations	410.4(A)
E3903.9	Lampholders in wet or damp locations	410.49
E3903.10	Bathtub and shower area.	410.4(D)
E3903.11	Luminaires in clothes closets	410.8(A), (B), (C), and (D)
Figure E3903.11	Closet storage space	Figure 410.8
E3903.12	Luminaire wiring—general	410.22
E3903.12.1	Polarization of luminaires	410.23
E3903.12.2	Luminaires as raceways	410.31

SECTION E3904 LUMINAIRE INSTALLATION

E3904.1	Outlet box covers	410.12
E3904.2	Combustible material at outlet boxes	410.13
E3904.3	Access	410.16(B)
E3904.4	Supports	410.15(A)
E3904.5	Means of support	410.16(A)
E3904.6	Exposed ballasts	410.76(A)
E3904.7	Combustible low-density cellulose fiberboard	410.76(B)
E3904.8	Recessed fixture clearance.	410.66(A)(1),(A)(2)
E3904.9	Recessed fixture installation.	410.66(B)

SECTION E3905 TRACK LIGHTING

E3905.1	Installation	410.101(A) and (B)
E3905.2	Fittings	410.101(A) and (D)
E3905.3	Connected load	410.101(B)
E3905.4	Prohibited locations	410.101(C)
E3905.5	Fastening	410.104
E3905.6	Grounding	410.105(B)

CHAPTER 40 APPLIANCE INSTALLATION

SECTION E4001 GENERAL

E4001.1	Scope	422.1 and 424.1
E4001.2	Installation	110.3(B) and 422.17
E4001.3	Flexible cords.	422.16
Table E4001.3	Flexible cord length	422.16(B)(1), (2) and (4)
E4001.4	Overcurrent protection	422.11
E4001.4.1	Single nonmotor-operated appliance	422.11(E)
E4001.5	Disconnecting means	422.30, 422.35 and 424.19

Table E4001.5 Disconnecting means 422.31(A),(B), 422.34, 422.35, 424.19, 424.20 and 440.14
 E4001.6 Support of ceiling-suspended paddle fans 422.18
 E4001.7 Snow-melting and deicing equipment protection 210.8(A)(3) Exception and 426.28

CHAPTER 41 SWIMMING POOLS

SECTION E4101 GENERAL

E4101.1 Scope Section 680.1
 E4101.2 Definitions 680.2

SECTION E4102 WIRING METHODS FOR POOLS, SPAS, HOT TUBS AND HYDROMASSAGE BATHTUBS

E4102.1 General . . 680.7, 680.23(B), 680.21(A), 680.23(F), 680.25(A), 680.40, 680.42, 680.43 and 680.70
 E4102.2 Flexible cords 680.7(A), (B), 680.22(B)(5), 680.42, and 680.43 Exception
 E4102.3 Double insulated pool pumps 680.21(B)

SECTION E4103 EQUIPMENT LOCATION AND CLEARANCES

E4103.1 Receptacle outlets 680.22(A)(6)
 E4103.1.1 Location 680.22(A)(1)
 E4103.1.2 Where required 680.22.(A)(3)
 E4103.1.3 Restricted space 680.22(A)(4)
 E4103.1.4 GFCI protection 680.22(A)(5)
 E4103.1.5 Indoor locations 680.43(A) and (A)(1)
 E4103.1.6 Indoor GFCI protection 680.43(A)(2)
 E4103.2 Switching devices 680.22(C), 680.43(C), 680.72
 E4103.3 Disconnecting means 680.12
 E4103.4 Luminaires and ceiling fans 680.22(B)
 E4103.4.1 Outdoor location 680.22(B)(1)
 E4103.4.2 Indoor location 680.22(B)(2)
 E4103.4.3 Existing lighting outlets and luminaires 680.22(B)(3)
 E4103.4.4 Indoor spas and hot tubs 680.43(B)
 E4103.4.5 GFCI protection in adjacent areas 680.22(B)(4)
 E4103.5 Overhead conductor clearances 680.8
 Table E4103.5 Overhead conductor clearances Table 680.8
 Figure E4103.5 Overhead conductor clearances Figure 680.8
 E4103.6 Underground wiring 680.10
 Table E4103.6 Underground wiring Table 680.10

SECTION E4104 BONDING

E4104.1 Performance 680.26(A)
 E4104.2 Bonded parts 680.26(B), 680.26(E), 680.42(B) and 680.43(D)(4)
 E4104.3 Parts not required to be bonded 680.43(D)(4) Exception
 E4104.4 Methods of bonding 680.26(A), 680.26(C), 680.26(D), 680.42(B) and 680.43(E)

SECTION E4105 GROUNDING

E4105.1 Equipment to be grounded 680.6
 E4105.2 Luminaires and related equipment 680.23(F)(2), 680.24(F)
 E4105.3 Nonmetallic conduit 680.23(B)(2)(b)
 E4105.4 Flexible cords 680.23(B)(3)
 E4105.5 Motors 680.21(A)(1)
 E4105.6 Panelboards 680.25(B) and (B)(1)
 E4105.6.1 Separate Buildings 680.25(B)(2)
 E4105.7 Cord-connected equipment Section 680.7
 E4105.8 Other equipment 680.6 and Article 250 Parts V, VI, and VII

SECTION E4106 EQUIPMENT INSTALLATION

E4106.1 Transformers 680.23(A)(2)
 E4106.2 Ground-fault circuit-interrupters 680.5
 E4106.3 Wiring on load side of ground-fault circuit-interrupters and transformers 680.23(F)(3)
 E4106.4 Underwater luminaires 680.23(A)(1),(A)(3) and (A)(7)

APPENDIX Q

E4106.4.1	Maximum voltage	680.23(A)(4)
E4106.4.2	Luminaire location	680.23(A)(5) and (A)(6)
E4106.5	Wet-niche luminaires	680.23(B)(1), (B)(2), (B)(4) and (B)(5)
E4106.5.1	Servicing	680.23(B)(6)
E4106.6	Dry-niche luminaires	680.23(C)(1) and (C)(2)
E4106.7	No-niche luminaires	680.23(D)
E4106.8	Through-wall lighting assembly	680.23(E)
E4106.9	Junction boxes and enclosures for transformers or ground-fault circuit interrupters	680.24(A) through (E)
E4106.9.1	Junction boxes	680.24(A)(1) and (A)(2)
E4106.9.2	Other enclosures	680.24(B)(1) and (2)
E4106.9.3	Protection of junction boxes and enclosures	680.24(C)
E4106.9.4	Grounding terminals	680.24(D)
E4106.9.5	Strain relief	680.24(E)
E4106.10	Underwater audio equipment	680.27(A)
E4106.10.1	Speakers	680.27(A)(1)
E4106.10.2	Wiring methods	680.27(A)(2)
E4106.10.3	Forming shell and metal screen	680.27(A)(3)
E4106.11	Electrically operated pool covers	680.27(B)(1) and (B)(2)
E4106.12	Electric pool water heaters	680.9
E4106.13	Pool area heating	680.27(C)
E4106.13.1	Unit heaters	680.27(C)(1)
E4106.13.2	Permanently wired radiant heaters	680.27(C)(2)
E4106.13.3	Radiant heating cables prohibited	680.27(C)(3)
E4106.14	Double insulated pool pumps	Section 680.21(B)
SECTION E4107	STORABLE SWIMMING POOLS	
E4107.1	Pumps	680.31
E4107.2	Ground-fault circuit-interrupters required	680.32
E4107.3	Luminaires	680.33
E4107.3.1	Fifteen (15) volts or less	680.33(A)
E4107.3.2	Not over 150 volts	680.33(B)
E4107.4	Receptacle locations	680.34
SECTION E4108	SPAS AND HOT TUBS	
E4108.1	Ground-fault circuit-interrupters	680.44(A) and (C)
E4108.2	Electric water heaters	680.9
E4108.3	Underwater audio equipment	680.43(G)
E4108.4	Emergency switch for spas and hot tubs	680.41
SECTION E4109	HYDROMASSAGE BATHTUBS	
E4109.1	Ground-fault circuit-interrupters	680.71
E4109.2	Other electric equipment	680.72
E4109.3	Accessibility	680.73
E4109.4	Bonding	680.74
CHAPTER 42	CLASS 2 REMOTE CONTROL, SIGNALING, AND POWER-LIMITED CIRCUITS	
SECTION E4201	GENERAL	
E4201.1	Scope	725.1
E4201.2	Definitions	Article 100 and Section 725.2
SECTION E4202	POWER SOURCES	
E4202.1	Power sources for Class 2 circuits	725.41(A)
E4202.2	Interconnection of power sources	725.41(B)
SECTION E4203	WIRING METHODS	
E4203.1	Wiring methods on supply side of Class 2 power source	725.51

E4203.2 Wiring methods and materials on load side of the
 Class 2 power source 725.52, 725.61, 725.82, Table 725.61
 Table E4203.2 Cable uses and permitted substitutions. 725.61 and Table 725.61
 E4203.2.1 Type CL2P cables 725.61(A) and 725.82(A)
 E4203.2.2 Type CL2 Cables 725.82(C)
 E4203.2.3 Type CL2X Cables 725.61(E)(4) and 725.82(D)
 E4203.2.4 Marking 725.82(L)

SECTION E4204 INSTALLATION REQUIREMENTS

E4204.1 Separation from other conductors. 725.55(A), (B), (C), (D)
 E4204.2 Other applications 725.55(J)
 E4204.3 Class 2 circuits with communication circuits 725.56(D)
 E4204.4 Class 2 cables with other circuit cables 725.56(E)(1) through (5)
 E4204.5 Installation of conductors and cables 725.7, 725.8, 725.58, 300.11(B)(2)

