

APPENDIX Q

ICC INTERNATIONAL RESIDENTIAL CODE ELECTRICAL PROVISIONS/NATIONAL ELECTRICAL CODE CROSS-REFERENCE

(This appendix is informative and is not part of the code. This table is a cross-reference of the *International Residential Code*, Chapters 34 through 43, and the 2008 *National Electrical Code*, NFPA 70).

International Residential Code	National Electrical Code
CHAPTER 34	GENERAL REQUIREMENTS
SECTION E3401	GENERAL
E3401.1	Applicability None
E3401.2	Scope 90.2
E3401.3	Not covered 90.2
E3401.4	Additions and alterations None
SECTION E3402	BUILDING STRUCTURE PROTECTION
E3402.1	Drilling and notching None
E3402.2	Penetrations of fire-resistance-rated assemblies 300.21
E3402.3	Penetrations of firestops and draftstops 300.21
SECTION E3403	INSPECTION AND APPROVAL
E3403.1	Approval 110.2
E3403.2	Inspection required None
E3403.3	Listing and labeling 110.3
SECTION E3404	GENERAL EQUIPMENT REQUIREMENTS
E3404.1	Voltages 110.4
E3404.2	Interrupting rating 110.9
E3404.3	Circuit characteristics 110.10
E3404.4	Protection of equipment 110.11
E3404.5	Unused openings 110.12(A)
E3404.6	Integrity of electrical equipment 110.12(C)
E3404.7	Mounting 110.13(A)
E3404.8	Energized parts guarded against accidental contact 110.27(A)
E3404.9	Prevent physical damage 110.27(B)
E3404.10	Equipment identification 110.21
E3404.11	Identification of disconnecting means 110.22
SECTION E3405	EQUIPMENT LOCATION AND CLEARANCES
E3405.1	Working space and clearances 110.26
Figure E3405.1	Working space and clearances 110.26(A)
	Footnote 1 110.26(F)(1)(a)
	Footnote 2 110.26(A)(3) and 110.26(E)
	Footnote 3 110.26(B)
	Footnote 4 230.70(A), 240.24(D), (E), & (F), Footnote 5
	Footnote 5 110.26(D)
E3405.2	Working clearances for energized equipment and panelboards 110.26(A)(1), (2), & (3)
E3405.3	Clearances over panelboards 110.26(F)(1)(a)
E3405.4	Location of clear spaces 110.26(B), 230.70(A) and 240.24(D), (E) & (F)
E3405.5	Access and entrance to working space 110.26(C)(1)
E3405.6	Illumination 110.26(D)
E3405.7	Headroom 110.26(E)

SECTION E3406	ELECTRICAL CONDUCTORS AND CONNECTIONS	
E3406.1	General	Articles 110, 300 and 310
E3406.2	Conductor material	110.5
E3406.3	Minimum size of conductors	310.5
E3406.4	Stranded conductors	310.3
E3406.5	Individual conductor insulation	310.2(A) and 310.8
E3406.6	Conductors in parallel	310.4
E3406.7	Conductors of the same circuit	300.3(B)
E3406.8	Aluminum and copper connections	110.14
E3406.9	Terminals	110.14(A)
E3406.10	Splices	110.14(B)
E3406.10.1	Continuity	300.13(A)
	Exception	300.13(A)
E3406.10.2	Device connections	250.148 and 300.13(B)
E3406.10.3	Length of conductor for splice or termination	300.14
E3406.11	Grounded conductor continuity	200.2(B)
SECTION E3407	CONDUCTOR IDENTIFICATION	
E3407.1	Grounded conductors	200.6(A), 200.6(B) and 310.12(A)
E3407.2	Equipment grounding conductors	250.119 and 310.12(B)
E3407.3	Ungrounded conductors	310.12(C), 310.12(C), Exception and 200.7(C)(1) & (C)(2)
E3407.4	Identification of terminals	200.10
E3407.4.1	Device terminals	200.10(A)
E3407.4.2	Receptacles, plugs, and connectors	200.10(B)
E3407.5	Polarity of connections	200.11
CHAPTER 35	ELECTRICAL DEFINITIONS	
SECTION 3501	GENERAL	Article 100, Definitions, 210.12(A)
CHAPTER 36	SERVICES	
SECTION E3601	GENERAL SERVICES	
E3601.1	Scope	230.1
E3601.2	Number of services	230.2
E3601.3	One building or other structure not to be supplied through another	230.3
E3601.4	Other conductors in raceway or cable	230.7
E3601.5	Raceway seal	230.8
E3601.6	Service disconnect required	230.70
E3601.6.1	Marking of service equipment and disconnects	230.66 and 230.70(B)
E3601.6.2	Service disconnect location	230.70 and 230.72(C)
E3601.7	Maximum number of disconnects	230.71(A)
SECTION E3602	SERVICE SIZE AND RATING	
E3602.1	Rating of ungrounded conductors	230.79(C) and (D)
E3602.2	Service load	220.82(A)
E3602.2.1	Services under 100 amperes	None
Table E3602.2	Minimum service load calculation	220.82 (B) and (C)
E3602.3	Rating of service disconnect	230.79 & 230.80
E3602.4	Voltage rating	220.82(a)
SECTION E3603	SERVICE, FEEDER AND GROUNDING ELECTRODE CONDUCTOR SIZING	
E3603.1	Grounded and ungrounded service conductor size	310.15(B)(6)
Table E3603.1	Service conductor and grounding electrode conductor sizing	Table 310.15(B)(6) and Table 250.66
	Footnote 1	250.64(E)
	Footnote 2	250.64(B)
	Footnote 3	250.64(B)
	Footnote 4	250.66(A) and (B)

E3603.2	Ungrounded service conductors for accessory buildings and structures	230.79(D)
	Exception 1	230.42 and 230.79(A)
	Exception 2	230.42 and 230.79(B)
E3603.3	Overload protection	230.90
E3603.3.1	Ungrounded conductor	230.90(A)
	Exception	230.90(A), Exception No. 3
E3603.3.2	Not in grounded conductor	230.90(B)
E3603.3.3	Location	230.91
E3603.4	Grounding electrode conductor size	250.66
E3603.5	Temperature limitations	110.14(C)(1)
SECTION E3604	OVERHEAD SERVICE-DROP AND SERVICE CONDUCTOR INSTALLATION	
E3604.1	Clearances on buildings	230.9
Figure E3604.1	Clearances from building openings	230.9
E3604.2	Vertical clearances	230.24
E3604.2.1	Above roofs	230.24(A)
	Exception 1	230.24(A), Exception No. 1
	Exception 2	230.24(A), Exception No. 2
	Exception 3	230.24(A), Exception No. 3
	Exception 4	230.24(A), Exception No. 4
Figure E3604.2.1	Clearances from roofs	230.24
E3604.2.2	Vertical clearance from grade	230.24(B)
	Item 1	230.24(B)(1)
	Item 2	230.24(B)(2)
	Item 3	230.24(B)(4)
E3604.3	Point of attachment	230.26
E3604.4	Means of attachment	230.27
E3604.5	Service masts as supports	230.28
E3604.6	Supports over buildings	230.29
SECTION E3605	SERVICE-ENTRANCE CONDUCTORS	
E3605.1	Insulation of service-entrance conductors	230.41
	Exception 1	230.41, Exception
	Exception 2	230.41, Exception
E3605.2	Wiring methods for services	230.43
E3605.3	Spliced conductors	230.46
E3605.4	Protection against physical damage	230.49
E3605.5	Protection of service cables against damage	230.50(A)
E3605.6	Direct sunlight exposure	310.8(D)
E3605.7	Mounting supports	230.51
E3605.8	Raceways to drain	230.53
E3605.9	Overhead service locations	230.54
E3605.9.1	Rain-tight service head	230.54(A)
E3605.9.2	Service cable, service head or gooseneck	230.54(B)
E3605.9.3	Service head location	230.54(C)
	Exception	230.54(C), Exception
E3605.9.4	Separately bushed openings	230.54(E)
E3605.9.5	Drip loops	230.54(F)
E3605.9.6	Conductor arrangement	230.54(G)
E3605.9.7	Secured	230.54(D)
SECTION E3606	SERVICE EQUIPMENT—GENERAL	
E3606.1	Service equipment enclosures	230.62
E3606.2	Working space	110.26
E3606.3	Available short-circuit current	110.9
E3606.4	Marking	230.66

SECTION E3607	SYSTEM GROUNDING	
E3607.1	System service ground	250.20(B)(1) and 250.24(A)
E3607.2	Location of grounding electrode conductor connection	250.24(A)(1) and (A)(5)
E3607.3	Buildings or structures supplied by feeder(s) or branch circuit(s)	250.32(A)
	Exception	250.32(A), Exception
E3607.3.1	Equipment grounding conductor	250.32(B) and Table 250.122
E3607.3.2	Grounded conductor.	250.32(B) Exception
E3607.4	Grounding electrode conductor	250.24(D)
E3607.5	Main bonding jumper	250.24(B)
E3607.6	Common grounding electrode	250.58
SECTION E3608	GROUNDING ELECTRODE SYSTEM	
E3608.1	Grounding electrode system.	250.50
E3608.1	Exception.	250.50 Exception
E3608.1.1	Metal underground water pipe	250.52(A)(1)
E3608.1.1.1	Installation	250.53(D) and 250.53(E)
E3608.1.2	Concrete-encased electrode.	250.50(A)(3)
E3608.1.3	Ground Rings.	250.52(A)(4), 250.53(F)
E3608.1.4	Rod and pipe electrodes.	250.52(A)(5)
E3608.1.4.1	Installation.	250.53(G)
E3608.1.5	Plate electrodes	250.52(A)(6) and 250.53(H)
E3608.1.6	Other listed electrodes	250.52(A)(6)
E3608.2	Bonding Jumper	250.53(C)
E3608.3	Rod, pipe and plate electrode requirements	250.53(A) (B) and (E)
E3608.4	Resistance of rod, pipe and plate electrodes	250.56
E3608.5	Aluminum Electrodes	250.52(B)(2)
E3608.6	Metal underground gas piping system	250.52(B)(1)
SECTION E3609	BONDING	
E3609.1	General	250.90
E3609.2	Bonding of service equipment	250.92(A)
E3609.3	Bonding to other systems.	250.94
E3609.4	Method of bonding at the service.	250.92(B)
E3609.4.1	Grounded service conductor	250.92(B)(1)
E3609.4.2	Threaded connections	250.92(B)(2)
E3609.4.3	Threadless couplings and connectors	250.92(B)(3)
E3609.4.4	Other devices	250.92(B)(4)
E3609.5	Sizing bonding jumper on supply side of service and main bonding jumper	250.102(C)
E3609.6	Metal water piping bonding	250.104(A)
E3609.7	Bonding other metal piping	250.104(B)
SECTION E3610	GROUNDING ELECTRODE CONDUCTORS	
E3610.1	Continuous	250.64(C) and (F)
E3610.2	Securing and protection against physical damage.	250.64(A) and (B)
E3610.3	Enclosures for grounding electrode conductors	250.64(E)
SECTION E3611	GROUNDING ELECTRODE CONDUCTOR CONNECTION TO GROUNDING ELECTRODES	
E3611.1	Methods of grounding connection to electrodes.	250.70
E3611.2	Accessibility	250.68(A)
E3611.3	Effective grounding path	250.68(B)
E3611.4	Protection of ground clamps and fittings	250.10
E3611.5	Clean surfaces.	250.12

CHAPTER 37	BRANCH CIRCUIT AND FEEDER REQUIREMENTS
SECTION E3701	GENERAL
E3701.1	Scope None
E3701.2	Branch-circuit and feeder ampacity 210.19(A) and 215.2(A)(1)
E3701.3	Selection of ampacity 310.15(A)(2)
E3701.4	Multioutlet branch circuits 210.19(A)(2)
E3701.5	Multiwire branch circuits 210.4
E3701.5.1	Disconnecting means 210.4(B)
E3701.5.2	Grouping 210.4(D)
SECTION E3702	BRANCH CIRCUIT RATINGS
E3702.1	Branch-circuit voltage limitations 210.6(A) and (B)
E3702.2	Branch-circuit ampere rating 210.3
E3702.3	Fifteen- and 20-ampere branch circuits 210.23(A)
E3702.4	Thirty-ampere branch circuits 210.23(B)
E3702.5	Branch circuits serving multiple loads or outlets 210.23(A)
E3702.6	Branch circuits serving a single motor 430.22(A)
E3702.7	Branch circuits serving motor-operated and combination loads 220.18(A)
E3702.8	Branch-circuit inductive lighting loads 220.18(B)
E3702.9	Branch-circuit load for ranges and cooking appliances Table 220.55, Note 4
E3702.9.1	Minimum branch circuit for ranges 210.19(A)(3)
E3702.10	Branch circuits serving heating loads 422.13 and 424.3(A) & (B)
E3702.11	Branch circuits for air-conditioning and heat pump equipment 440.35, 440.4(B) and 440.62(A)
E3702.12	Branch circuits serving room air conditioners 440.62(A)
E3702.12.1	Where no other loads are supplied 440.62(B)
E3702.12.2	Where lighting units or other appliances are also supplied 440.62(C)
E3702.13	Branch-circuit requirement—summary 210.24 and 210.25
Table E3702.13	Branch-circuit requirement—summary Table 210.24
SECTION E3703	REQUIRED BRANCH CIRCUITS
E3703.1	Branch circuits for heating 422.12 and 422.12 Exception
E3703.2	Kitchen and dining area receptacles 210.52 (B)(1)
E3703.3	Laundry circuit 210.23(A) Exception and 210.11(C)(2)
E3703.4	Bathroom branch circuits 210.11(C)(3)
E3703.5	Number of branch circuits 210.11(A)
E3703.6	Branch-circuit load proportioning 210.11(B)
SECTION E3704	FEEDER REQUIREMENTS
E3704.1	Conductor size Table 310.15(B)(6), Sections 215.2 (A)(3), (A)(4) and 220.10(A)
E3704.2	Feeder loads 220.12
Table E3704.2(1)	Feeder load calculation Table 220.12, Table 220.42(C), Sections 220.14, 220.50, 220.51, 220.52, 220.53, 220.54, 220.55 and 220.60
Table E3704.2(2)	Demand loads for electric ranges, wall-mounted ovens, counter-mounted cooking units and other cooking appliances over 1 ³ / ₄ kVA rating Table 220.55
E3704.3	Feeder neutral load 220.61
E3704.4	Lighting and general use receptacle load 220.14(J), Table 220.12
E3704.5	Ampacity and calculated loads 220.40
E3704.6	Equipment grounding conductor 215.6
SECTION E3705	CONDUCTOR SIZING AND OVERCURRENT PROTECTION
E3705.1	General 310.15(A)
Table E3705.1	Allowable ampacities Table 310.16
E3705.2	Correction factors for ambient temperatures Table 310.16
Table E3705.2	Ambient temperature correction factors Table 310.16, Correction factors
E3705.3	Adjustment factor for conductor proximity 310.15(B)(2)(a)
Table E3705.3	Conductor proximity adjustment factors Table 310.15(B)(2)(a)
E3705.4	Temperature limitations 110.14(C)

APPENDIX Q

E3705.4.1	Conductors rated 60°C	110.14(C)(1)(a)
E3705.4.2	Conductors rated 75°C	110.14(C)(1)(b)
E3705.4.3	Separately installed pressure connectors	110.14(C)(2)
E3705.4.4	Conductors of type NM cable	334.80 and 334.112
E3705.5	Overcurrent protection required	Table 310.15(B)(6), Sections 240.4, 240.21
E3705.5.1	Cords	240.5
E3705.5.2	Overcurrent devices of the next higher size	240.4(B)
E3705.5.3	Small conductors	240.4(D)
E3705.5.4	Air conditioning and heat pump equipment	240.4(G)
E3705.6	Fuses and fixed trip circuit breakers	Section 240.6
E3705.7	Location of overcurrent devices in or on premises	240.24(A),(C),(D),(E),(F)
E3705.8	Ready access for occupants	Section 240.24(B)
E3705.9	Enclosures for overcurrent devices	Section 240.30 (A) and (B)
SECTION E3706 PANELBOARDS		
E3706.1	Panelboard rating	408.30
E3706.2	Panelboard circuit identification	408.4
E3706.3	Panelboard overcurrent protection	408.36
E3706.4	Grounded conductor terminations	408.41
E3706.5	Back-fed devices	408.36(D)
CHAPTER 38 WIRING METHODS		
SECTION E3801 GENERAL REQUIREMENTS		
E3801.1	Scope	Section 300.1
E3801.2	Allowable wiring methods	Sections 110.8 and 300.3(A)
Table E3801.2	Allowable wiring methods	None
E3801.3	Circuit conductors	300.3(B)
E3801.4	Wiring method applications	Chapter 3 and Section 300.2
Table E3801.4	Allowable applications for wiring methods	Chapter 3 and Section 300.2
SECTION E3802 ABOVE-GROUND INSTALLATION REQUIREMENTS		
E3802.1	Installation and support requirements	Chapter 3
Table E3802.1	General installation and support requirements for wiring methods	Chapter 3
E3802.2	Cables in accessible attics	320.23 and 334.23
E3802.2.1	Across structural members	320.23(A) and 334.23
E3802.2.2	Cable installed through or parallel to framing members	320.23(B)
E3802.3	Exposed cable	320.15 and 334.15
E3802.3.1	Surface installation	334.15(A)
E3802.3.2	Protection from physical damage	334.15(B)
E3802.3.3	Locations exposed to direct sunlight	310.8(D)
E3802.4	In unfinished basements	334.15(C)
E3802.5	Bends	334.24 and 338.24
E3802.6	Raceways exposed to different temperatures	Section 300.7(A)
E3802.7	Wet locations above grade	300.9
SECTION E3803 UNDERGROUND INSTALLATION REQUIREMENTS		
E3803.1	Minimum cover requirements	300.5(A)
Table E3803.1	Minimum cover requirements, burial in inches	Table 300.5
E3803.2	Warning ribbon	300.5(D)(3)
E3803.3	Protection from damage	300.5(D)
E3803.4	Splices and taps	300.5(E)
E3803.5	Backfill	300.5(F)
E3803.6	Raceway seals	300.5(G)
E3803.7	Bushing	300.5(H)
E3803.8	Single conductors	300.5(I)
E3803.9	Ground movement	Section 300.5(J)

E3803.10	Wet locations	300.5(B)
E3803.11	Under buildings	300.5(C)

CHAPTER 39 POWER AND LIGHTING DISTRIBUTION

SECTION E3901 RECEPTACLE OUTLETS

E3901.1	General	210.50 and 210.52
E3901.2	General-use receptacle distribution	210.52(A)
E3901.2.1	Spacing	210.52(A)(2)
E3902.2.2	Wall space	210.52(A)(2)
E3901.2.3	Floor receptacles	210.52(3)
E3901.3	Small appliance receptacles	210.52(B)(1)
E3901.3.1	Other outlets prohibited	210.52(B)(2)
E3901.3.2	Limitations	210.52(B)(3)
E3901.4	Countertop receptacles	210.52(C)
E3901.4.1	Wall counter space	210.52(C)(1)
E3901.4.2	Island counter spaces	210.52(C)(2)
E3901.4.3	Peninsular counter space	210.52(C)(3)
E3901.4.4	Separate spaces	210.52(C)(4)
E3901.4.5	Receptacle outlet location	210.52(C)(5)
E3901.5	Appliance outlets	210.50(C)
E3901.6	Bathroom	210.52(D)
E3901.7	Outdoor outlets	210.52(E)
E3901.8	Laundry areas	210.52(F)
E3901.9	Basements and garages	210.52(G)
E3901.10	Hallways	210.52(H)
E3901.11	HVAC outlet	210.63

SECTION E3902 GROUND-FAULT AND ARC-FAULT CIRCUIT-INTERRUPTER PROTECTION

E3902.1	Bathroom receptacles	210.8(A)(1)
E3902.2	Garage and accessory building receptacles	210.8(A)(2)
E3902.3	Outdoor receptacles	210.8(A)(3)
E3902.4	Crawl space receptacles	210.8(A)(4)
E3902.5	Unfinished basement receptacles	210.8(A)(5)
E3902.6	Kitchen receptacles	210.8(A)(6)
E3902.7	Laundry, utility and wet bar sink receptacles	210.8(A)(7)
E3902.8	Boathouse receptacles	210.8(A)(8)
E3902.9	Boat hoists	210.8(C)
E3902.10	Electrically heated floors	424.44(G)
E3902.11	Exempt receptacles	210.8(A)(2)
E3902.12	Bedroom outlets	210.12

SECTION E3903 LIGHTING OUTLETS

E3903.1	General	210.70(A)
E3903.2	Habitable rooms	210.70(A)(1)
E3903.3	Additional locations	210.70(A)(2)
E3903.4	Storage or equipment spaces	210.70(A)(3)

SECTION E3904 GENERAL INSTALLATION REQUIREMENTS

E3904.1	Electrical continuity of metal raceways and enclosures	300.10
E3904.2	Mechanical continuity—raceways and cables	300.12
E3904.3	Securing and supporting	300.11(A)
E3904.3.1	Prohibited means of support	300.11(C)
E3904.4	Raceways as means of support	300.11(B)
E3904.5	Raceway installations	300.18
E3904.6	Conduit and tubing fill	300.17 and Chapter 9, Table 1 and Annex C

APPENDIX Q

Tables E3904.6(1)-
E3904.6(10) Maximum number of conductors in conduit or tubing 300.17 and Chapter 9, Table 1, Note 1
E3904.7 Air handling—stud cavity and joist spaces Section 300.22(C), Exception

CHAPTER E3905 BOXES, CONDUIT BODIES, AND FITTINGS

E3905.1 Box, conduit body or fitting—where required 300.15
E3905.1.1 Equipment 300.15(B)
E3905.1.2 Protection 300.15(C)
E3905.1.3 Integral enclosure 300.15(E)
E3905.1.4 Fitting 300.15(F)
E3905.1.5 Buried conductors 300.15(G)
E3905.1.6 Luminaires 300.15(J)
E3905.1.7 Closed loop 300.15(M)
E3905.2 Metal boxes 314.4
E3905.3 Nonmetallic boxes 314.3
E3905.3.1 Nonmetallic-sheathed cable and nonmetallic boxes 314.17(C)
E3905.3.2 Securing to box 314.17(C)
E3905.3.3 Conductor rating 314.17(C)
E3905.4 Minimum depth of outlet boxes 314.24
E3905.5 Boxes enclosing flush-mounted devices 314.19
E3905.6 Boxes at luminaire (lighting fixture) outlets 314.27(A)
E3905.7 Maximum luminaire (fixture) weight 314.27(B)
E3905.8 Floor boxes 314.27(C)
E3905.9 Boxes at fan outlets 314.27(D)
E3905.10 Utilization equipment 314.27(E)
E3905.11 Conduit bodies, junction, pull and outlet boxes to be accessible 314.29
E3905.12 Damp or wet locations 314.15
E3905.13 Number of conductors in outlet, device, and junction boxes and conduit boxes 314.16
E3905.13.1 Box volume calculations 314.16(A)
Table E3905.13.1 Maximum number of conductors in metal boxes Table 314.16
E3905.13.1.1 Standard boxes 314.16(A)(1)
E3905.13.1.2 Other boxes 314.16(A)(2)
E3905.13.2 Box fill calculations 314.16(B)
E3905.13.2.1 Conductor fill 314.16(B)(1) and Table 314.16
Table E3905.13.2.1 Volume allowance required per conductor Table 314.16(B)
E3905.13.2.2 Clamp fill 314.16(B)(2)
E3905.13.2.3 Support fittings fill 314.16(B)(3)
E3905.13.2.4 Device or equipment fill 314.16(B)(4)
E3905.13.2.5 Equipment grounding conductor fill 314.16(B)(5)
E3905.13.3 Conduit bodies 314.16(C)(1)
E3905.13.3.1 Splices, taps or devices 314.16(C)(2)

SECTION E3906 INSTALLATION OF BOXES, CONDUIT BODIES AND FITTINGS

E3906.1 Conductors entering boxes, conduit bodies or fittings 314.17
E3906.1.1 Insulated fittings 300.4(G)
E3906.2 Openings 314.17(A)
E3906.3 Metal boxes, conduit bodies and fittings 314.17, 314.17(B)
E3906.4 Unused openings 110.12(A)
E3906.5 In wall or ceiling 314.20
E3906.6 Plaster, gypsum board and plasterboard 314.21
E3906.7 Exposed surface extensions 314.22
E3906.8 Supports 314.23
E3906.8.1 Surface mounting 314.23(A)
E3906.8.2 Structural mounting 314.23(B)
E3906.8.2.1 Nails 314.23(B)(1)
E3906.8.2.2 Braces 314.23(B)(2)

E3906.8.3	Mounting in finished surfaces	314.23(C)
E3906.8.4	Raceway supported enclosures without devices or fixtures	314.23(E)
E3906.8.5	Raceway supported enclosures with devices or fixtures	314.23(F)
E3906.8.6	Enclosures in concrete or masonry	314.23(G)
E3906.9	Covers and canopies	314.25
E3906.10	Metal covers and plates	314.25(A)
E3906.11	Exposed combustible finish	314.25(B)
SECTION E3907	CABINETS AND PANELBOARDS	
E3907.1	Enclosures for switches or overcurrent devices	312.8
E3907.2	Damp or wet locations	312.2(A)
E3907.3	Position in wall	312.3
E3907.4	Repairing plaster, drywall and plasterboard	312.4
E3907.5	Unused openings	110.12(A), 408.7
E3907.6	Conductors entering cabinets.	300.4(F) and 312.5(B)
E3907.7	Openings to be closed.	312.5(A)
E3907.8	Cables.	312.5(C)
SECTION E3908	GROUNDING	
E3908.1	Metal enclosures	250.86
E3908.2	Equipment fastened in place or connected by permanent wiring methods (fixed).	250.110(1), (2), and (3)
E3908.3	Specific equipment fastened in place or connected by permanent wiring methods	250.112(J), (L), and (M)
E3908.4	Performance of fault current path	250.4(A)(5)
E3908.5	Earth as a grounding conductor	250.4(A)(5)
E3908.6	Load-side neutral	250.24(A)(5)
E3908.7	Load-side equipment	250.142 (B)
E3908.8	Types of equipment grounding conductors.	250.118
E3908.8.1	Flexible metal conduit	250.118(5)
E3908.8.2	Liquid-tight flexible metal conduit.	250.118(6)
E3908.8.3	Nonmetallic sheathed cable (Type NM)	334.108
E3908.9	Equipment fastened in place or connected by permanent wiring methods.	250.134
E3908.10	Methods of equipment grounding	250 Part (VII)
E3908.11	Equipment grounding conductor installation	250.120
E3908.12	Equipment grounding conductor size	250.122(A) and (B)
Table E3908.12	Equipment grounding conductor sizing	Table 250.122
E3908.12.1	Multiple circuits	250.122(C)
E3908.13	Continuity and attachment of equipment grounding conductors to boxes	250.148
E3908.14	Connecting receptacle grounding terminal to box	250.146(A), (B), and (C)
E3908.15	Metal boxes	250.8, 250.148(C)
E3908.16	Nonmetallic boxes	250.148(D)
E3908.17	Clean surfaces	250.12
E3908.18	Bonding other enclosures	250.96(A)
E3908.19	Size of equipment bonding jumper on load side of service.	250.102(D)
E3908.20	Installation—equipment bonding jumper	250.102(E)
SECTION E3909	FLEXIBLE CORDS	
E3909.1	Where permitted	400.7 and 400.8
E3909.2	Loading and protection	240.4, 240.5(A), 240.5(B)(1), 400.5, and 400.13
Table E3909.2	Maximum ampere load for flexible cords	Table 400.5(A)
E3909.3	Splices	400.9
E3909.4	Attachment plugs.	400.7(B)

CHAPTER 40 DEVICES AND LIGHTING FIXTURES**SECTION E4001 SWITCHES**

E4001.1	Rating and application of snap switches	404.14(A)
E4001.2	CO/ALR snap switches	404.14(C)
E4001.3	Indicating	404.7
E4001.4	Time switches and similar devices	404.5
E4001.5	Grounding of enclosures	404.12
E4001.6	Access	404.8(A)
E4001.7	Wet locations	404.4
E4001.8	Grounded conductors	404.2(B)
E4001.9	Switch connections	404.2(A)
E4001.10	Box mounted	404.10(B)
E4001.11	Snap switch faceplates	404.9(A)
E4001.11.1	Faceplate grounding	404.9(B)
E4001.12	Dimmer switches	404.14(E)
E4001.13	Multipole snap switches	404.8(C)

SECTION E4002 RECEPTACLES

E4002.1	Rating and type	406.2(A)(B)
E4002.1.1	Single receptacle	210.21(B)(1)
E4002.1.2	Two or more receptacles	210.21(B)(3)
Table E4002.1.2	Receptacle ratings for various size multioutlet circuits	Table 210.21(B)(3)
E4002.2	Grounding type	406.3(A)
E4002.3	CO/ALR receptacles	406.2(C)
E4002.4	Faceplates	406.5(B)
E4002.5	Position of receptacle faces	406.4(D), and 406.5
E4002.6	Receptacles mounted in boxes	406.4(A), and 406.4(B)
E4002.7	Receptacles mounted on covers	406.4(C)
E4002.8	Damp locations	406.8(A)
E4002.9	15- and 20-ampere receptacles in wet locations	406.8(B)(1)
E4002.10	Other receptacles in wet locations	406.8(B)(2)
E4002.11	Bathtub and shower space	406.8(C)
E4002.12	Flush mounting with faceplate	406.8(E)
E4002.13	Exposed terminals	406.4(F)
E4002.14	Tamper-resistant receptacles	406.11

SECTION E4003 LUMINAIRES

E4003.1	Energized parts	410.5
E4003.2	Luminaires near combustible material	410.11
E4003.3	Exposed conductive parts	410.42(A)
E4003.4	Screw-shell type	410.90
E4003.5	Recessed incandescent luminaires	410.115(C)
E4003.6	Thermal protection	410.130(E)(1)
E4003.7	High-intensity discharge luminaires	410.130(F)
E4003.8	Metal halide lamp containment	410.130(F)(5)
E4003.9	Wet or damp locations	410.10(A)
E4003.10	Lampholders in wet or damp locations	410.96
E4003.11	Bathtub and shower area	410.10(D)
E4003.12	Luminaires in clothes closets	410.2 & 410.16(A), (B), (C), and (D)
Figure E4003.12	Closet storage space	Figure 410.2
E4003.13	Luminaire wiring—general	410.48
E4003.13.1	Polarization of luminaires	410.50
E4003.13.2	Luminaires as raceways	410.64

SECTION E4004 LUMINAIRE INSTALLATION

E4004.1	Outlet box covers	410.22
---------	-----------------------------	--------

E4004.2	Combustible material at outlet boxes	410.23
E4004.3	Access	410.8
E4004.4	Supports	410.30(A)
E4004.5	Means of support	410.36(A)
E4004.6	Exposed ballasts	410.136(A)
E4004.7	Combustible low-density cellulose fiberboard	410.136(B)
E4004.8	Recessed fixture clearance	410.116(A)(1),(A)(2)
E4004.9	Recessed fixture installation	410.116(B)
SECTION E4005 TRACK LIGHTING		
E4005.1	Installation	410.151(A) and (B)
E4005.2	Fittings	410.151(A) and (D)
E4005.3	Connected load	410.151(B)
E4005.4	Prohibited locations	410.151(C)
E4005.5	Fastening	410.154
E4005.6	Grounding	410.155(B)
CHAPTER 41 APPLIANCE INSTALLATION		
SECTION E4101 GENERAL		
E4101.1	Scope	422.1 and 424.1
E4101.2	Installation	110.3(B) and 422.17
E4101.3	Flexible cords	422.16
Table E4101.3	Flexible cord length	422.16(B)(1), (2) and (4)
E4101.4	Overcurrent protection	422.11
E4101.4.1	Single nonmotor-operated appliance	422.11(E)
E4101.5	Disconnecting means	422.30, 422.35 and 424.19
Table E4101.5	Disconnecting means	422.31(A),(B), 422.34, 422.35, 424.19, 424.20 and 440.14
E4101.6	Support of ceiling-suspended paddle fans	422.18
E4101.7	Snow-melting and deicing equipment protection	210.8(A)(3) Exception and 426.28
CHAPTER 42 SWIMMING POOLS		
SECTION E4201 GENERAL		
E4201.1	Scope	Section 680.1
E4201.2	Definitions	680.2
SECTION E4202 WIRING METHODS FOR POOLS, SPAS, HOT TUBS AND HYDROMASSAGE BATH TUBS		
E4202.1	General	680.7, 680.23(B), 680.21(A), 680.23(F), 680.25(A), 680.40, 680.42, 680.43 and 680.70
E4202.2	Flexible cords	680.7(A), (B), 680.22(B)(5), 680.23(B)(3), 680.42, and 680.43 Exception
E4202.3	Double insulated pool pumps	680.21(B)
SECTION E4203 EQUIPMENT LOCATION AND CLEARANCES		
E4203.1	Receptacle outlets	680.22(A)(5)
E4203.1.1	Location	680.22(A)(1)
E4203.1.2	Where required	680.22.(A)(3)
E4203.1.3	GFCI protection	680.22(B)
E4203.1.4	Indoor locations	680.43(A) and (A)(1)
E4203.1.5	Indoor GFCI protection	680.43(A)(2)
E4203.2	Switching devices	680.22(D), 680.43(C), 680.72
E4203.3	Disconnecting means	680.12
E4203.4	Luminaires and ceiling fans	680.22(C)
E4203.4.1	Outdoor location	680.22(C)(1)
E4203.4.2	Indoor location	680.22(C)(2)
E4203.4.3	Existing lighting outlets and luminaires	680.22(C)(3)
E4203.4.4	Indoor spas and hot tubs	680.43(B)
E4203.4.5	GFCI protection in adjacent areas	680.22(C)(4)
4203.5	Other outlets	680.22(E)

APPENDIX Q

E4203.6 Overhead conductor clearances 680.8
Table E4203.6 Overhead conductor clearances Table 680.8
E4203.7 Underground wiring 680.10
Table E4203.7 Underground wiring Table 680.10

SECTION E4204 BONDING

E4204.1 Performance 680.26(A)
E4204.2 Bonded parts 680.26(B), 680.26(E), 680.42(B) and 680.43(D)(4)
E4204.3 Pool water 680.26(C)
E4204.4 Bonding of outdoor hot tubs and spas 680.42 and 680.42(B)
E4204.5 Bonding of indoor hot tubs and spas 680.43 (D)
E4204.5.1 Methods 680.43(E)
E4204.5.2 Connections 680.26(B)

SECTION E4205 GROUNDING

E4205.1 Equipment to be grounded 680.6
E4205.2 Luminaires and related equipment 680.23(F)(2), 680.24(F)
E4205.3 Nonmetallic conduit 680.23(B)(2)(b)
E4205.4 Flexible cords 680.23(B)(3)
E4205.5 Motors 680.21(A)(1)
E4205.6 Feeders 680.25(B) and (B)(1)
E4205.6.1 Separate Buildings 680.25(B)(2)
E4205.7 Cord-connected equipment Section 680.7
E4205.8 Other equipment 680.6 and Article 250 Parts V, VI, and VII

SECTION E4206 EQUIPMENT INSTALLATION

E4206.1 Transformers 680.23(A)(2)
E4206.2 Ground-fault circuit-interrupters 680.5
E4206.3 Wiring on load side of ground-fault circuit-interrupters and transformers 680.23(F)(3)
E4206.4 Underwater luminaires 680.23(A)(1),(A)(3) and (A)(7)
E4206.4.1 Maximum voltage 680.23(A)(4)
E4206.4.2 Luminaire location 680.23(A)(5) and (A)(6)
E4206.5 Wet-niche luminaires 680.23(B)(1), (B)(2), (B)(4) and (B)(5)
E4206.5.1 Servicing 680.23(B)(6)
E4206.6 Dry-niche luminaires 680.23(C)(1) and (C)(2)
E4206.7 No-niche luminaires 680.23(D)
E4206.8 Through-wall lighting assembly 680.23(E)
E4206.9 Junction boxes and enclosures for transformers or
ground-fault circuit interrupters 680.24(A) through (E)
E4206.9.1 Junction boxes 680.24(A)(1) and (A)(2)
E4206.9.2 Other enclosures 680.24(B)(1) and (2)
E4206.9.3 Protection of junction boxes and enclosures 680.24(C)
E4206.9.4 Grounding terminals 680.24(D)
E4206.9.5 Strain relief 680.24(E)
E4206.10 Underwater audio equipment 680.27(A)
E4206.10.1 Speakers 680.27(A)(1)
E4206.10.2 Wiring methods 680.27(A)(2)
E4206.10.3 Forming shell and metal screen 680.27(A)(3)
E4206.11 Electrically operated pool covers 680.27(B)(1) and (B)(2)
E4206.12 Electric pool water heaters 680.9
E4206.13 Pool area heating 680.27(C)
E4206.13.1 Unit heaters 680.27(C)(1)
E4206.13.2 Permanently wired radiant heaters 680.27(C)(2)
E4206.13.3 Radiant heating cables prohibited 680.27(C)(3)

SECTION E4207 STORABLE SWIMMING POOLS

E4207.1 Pumps 680.31
E4207.2 Ground-fault circuit-interrupters required 680.32

E4207.3	Luminaires	680.33
E4207.3.1	Fifteen (15) volts or less	680.33(A)
E4207.3.2	Not over 150 volts	680.33(B)
E4207.4	Receptacle locations	680.34
SECTION E4208	SPAS AND HOT TUBS	
E4208.1	Ground-fault circuit-interrupters	680.44(A) and (C)
E4208.2	Electric water heaters	680.9
E4208.3	Underwater audio equipment	680.43(G)
E4208.4	Emergency switch for spas and hot tubs	680.41
SECTION E4209	HYDROMASSAGE BATHTUBS	
E4209.1	Ground-fault circuit-interrupters	680.71
E4209.2	Other electric equipment	680.72
E4209.3	Accessibility	680.73
E4209.4	Bonding	680.74
CHAPTER 43	CLASS 2 REMOTE CONTROL, SIGNALING, AND POWER-LIMITED CIRCUITS	
SECTION E4301	GENERAL	
E4301.1	Scope	725.1
E4301.2	Definitions	Article 100 and Section 725.2
SECTION E4302	POWER SOURCES	
E4302.1	Power sources for Class 2 circuits	725.121(A)
E4302.2	Interconnection of power sources	725.121(B)
SECTION E4303	WIRING METHODS	
E4303.1	Wiring methods on supply side of Class 2 power source	725.127
E4303.2	Wiring methods and materials on load side of the Class 2 power source	725.130, 725.154, 725.179, Table 725.154(G)
Table E4303.2	Cable uses and permitted substitutions	725.154 and Table 725.154(G)
E4303.2.1	Type CL2P cables	725.154(A) and 725.179A)
E4303.2.2	Type CL2 Cables	725.179(C)
E4303.2.3	Type CL2X Cables	725.154(E)(4) and 725.179(D)
E4303.2.4	Marking	725.179(L)
SECTION E4304	INSTALLATION REQUIREMENTS	
E4304.1	Separation from other conductors	725.136(A), (B), (C), (D)
E4304.2	Other applications	725.136(J)
E4304.3	Class 2 circuits with communication circuits	725.139(D)
E4304.4	Class 2 cables with other circuit cables	725.139(E)(1) through (5)
E4304.5	Installation of conductors and cables	725.21, 725.24, 725.143, 300.11(B)(2)

