CHAPTER 9

VENTS

SECTION 901 GENERAL

- **901.1 Scope.** The provisions of this chapter shall govern the materials, design, construction and installation of vent systems
- **901.2 Trap seal protection.** The plumbing system shall be provided with a system of vent piping that will permit the admission or emission of air so that the seal of any fixture trap shall not be subjected to a pneumatic pressure differential of more than 1 inch of water column (249 Pa).
 - **901.2.1 Venting required.** Every trap and trapped fixture shall be vented in accordance with one of the venting methods specified in this chapter. All fixtures discharging downstream from a water closet shall be individually vented except as provided in Section 911.
- **901.3 Chemical waste vent system.** The vent system for a chemical waste system shall be independent of the sanitary vent system and shall terminate separately through the roof to the open air.
- **901.4 Use limitations.** The plumbing vent system shall not be utilized for purposes other than the venting of the plumbing system.
- **901.5 Tests.** The vent system shall be tested in accordance with Section 312.
- 901.6 Engineered systems. Deleted.

SECTION 902 MATERIALS

- **902.1 Vents.** The materials and methods utilized for the construction and installation of venting systems shall comply with the applicable provisions of Section 702.
- **902.2 Sheet copper.** Sheet copper for vent pipe flashings shall conform to ASTM B 152 and shall weigh not less than 8 ounces per square foot (2.5 kg/m²).
- **902.3 Sheet lead.** Sheet lead for vent pipe flashings shall weigh not less than 3 pounds per square foot (15 kg/m²) for field-constructed flashings and not less than 2.5 pounds per square foot (12 kg/m²) for prefabricated flashings.

SECTION 903 VENT STACKS AND STACK VENTS

903.1 Stack required. Every building in which plumbing is installed shall have at least one stack the size of which is not less than one-half of the required size of the building drain, and not less than 2 inches (51 mm) in diameter. Such stack shall run undiminished in size and as directly as possible from the building

drain through to the open air or to a vent header that extends to the open air.

- **903.1.1** Connection to drainage system. A vent stack shall connect to the building drain or to the base of a drainage stack in accordance with Section 903.4. A stack vent shall be an extension of the drainage stack. For townhouses and one- and two-family dwellings, the main vent shall connect to the building drain, building stack or branch thereof not less than 3 inches (76 mm) in size.
- **903.2 Vent stack required.** A vent stack shall be required for every drainage stack that is five branch intervals or more.
- **903.3 Vent termination.** Every vent stack or stack vent shall extend outdoors and terminate to the open air.
- **903.4 Vent connection at base.** Every vent stack shall connect to the base of the drainage stack. The vent stack shall connect at or below the lowest horizontal branch. Where the vent stack connects to the building drain, the connection shall be located downstream of the drainage stack and within a distance of 10 times the diameter of the drainage stack.
- 903.5 Vent headers. Stack vents and vent stacks connected into a common vent header at the top of the stacks and extending to the open air at one point shall be sized in accordance with the requirements of Section 916.1. The number of fixture units shall be the sum of all fixture units on all stacks connected thereto, and the developed length shall be the longest vent length from the intersection at the base of the most distant stack to the vent terminal in the open air, as a direct extension of one stack.

SECTION 904 VENT TERMINALS

- **904.1 Roof extension.** All open vent pipes that extend through a roof shall be terminated at least 6 inches (152 mm) above the roof, except where the roof is accessible by the public or the building tenants, the vent extensions shall be run at least 7 feet (2134 mm) above the roof.
- **904.2 Frost closure.** Where the 97.5-percent value for outside design temperature is 0°F (-18°C) or less, every vent extension through a roof or wall shall be a minimum of 3 inches (76 mm) in diameter. Any increase in the size of the vent shall be made inside the structure a minimum of 1 foot (305 mm) below the roof or inside the wall.
- **904.3 Flashings.** The juncture of each vent pipe with the roof line shall be made water tight by an approved flashing.
- **904.4 Prohibited use.** Vent terminals shall not be used as a flag pole or to support flag poles, television aerials or similar items, except when the piping has been anchored in an approved manner.

904.5 Location of vent terminal. An open vent terminal from a drainage system shall not be located directly beneath any door, openable window, or other air intake opening of the building or of an adjacent building, and any such vent terminal shall not be within 10 feet (3048 mm) horizontally of such an opening unless it is at least 2 feet (610 mm) above the top of such opening.

904.6 Extension through the wall. Vent terminals extending through the wall shall terminate a minimum of 10 feet (3048 mm) from the lot line and 10 feet (3048 mm) above average ground level. Vent terminals shall not terminate under the overhang of a structure with soffit vents. Side wall vent terminals shall not terminate horizontally to prevent birds or rodents from entering or blocking the vent opening.

904.7 Extension outside a structure. In climates where the 97.5-percent value for outside design temperature is less than 0°F (-18°C), vent pipes installed on the exterior of the structure shall be protected against freezing by insulation, heat or both.

SECTION 905 VENT CONNECTIONS AND GRADES

905.1 Connection. All individual, branch and circuit vents shall connect to a vent stack, stack vent, air admittance valve or extend to the open air.

905.2 Grade. All vent and branch vent pipes shall be so graded and connected as to drain back to the drainage pipe by gravity.

905.3 Vent connection to drainage system. Every dry vent connecting to a horizontal drain shall connect above the centerline of the horizontal drain pipe.

905.4 Vertical rise of vent. Every dry vent shall rise vertically to a minimum of 6 inches (152 mm) above the flood level rim of the highest trap or trapped fixture being vented.

Exception: When vents for interceptors and isolated floor drains are not located near an adjacent wall, the vent must rise 6 inches (152 mm) vertically before turning horizontally and continuing to the nearest wall. For cleaning purposes, a cleanout the same size as the vent shall be installed.

905.5 Height above fixtures. A connection between a vent pipe and a vent stack or stack vent shall be made at least 6 inches (152 mm) above the flood level rim of the highest fixture served by the vent. Horizontal vent pipes forming branch vents, relief vents or loop vents shall be at least 6 inches (152 mm) above the flood level rim of the highest fixture served.

905.6 Vent for future fixtures. Where the drainage piping has been roughed-in for future fixtures, a rough-in connection for a vent shall be installed. The vent size shall be not less than one-half the diameter of the rough-in drain to be served. The vent rough-in shall connect to the vent system, or shall be vented by other means as provided for in this chapter. The connection shall be identified to indicate that it is a vent.

TABLE 906.1 MAXIMUM DISTANCE OF FIXTURE TRAP FROM VENT

SIZE OF TRAP (inches)	SIZE OF FIXTURE DRAIN (inches)	SLOPE (inch per foot)	DISTANCE FROM TRAP (feet)
11/4	11/4	1/4	31/2
11/4	11/2	¹ / ₄	5
11/2	11/2	1/4	5
11/2	2	1/4	6
2	2	1/4	6
3	3	1/8	10
4	4	1/8	12

For SI: 1 inch = 25.4 mm, 1 foot = 304.8 mm,

1 inch per foot = 83.3 mm/m.

SECTION 906 FIXTURE VENTS

906.1 Distance of trap from vent. Each fixture trap shall have a protecting vent located so that the slope and the developed length in the fixture drain from the trap weir to the vent fitting are within the requirements set forth in Table 906.1.

906.2 Venting of fixture drains. The total fall in a fixture drain due to pipe slope shall not exceed the diameter of the fixture drain, nor shall the vent connection to a fixture drain, except for water closets, be below the weir of the trap.

906.3 Crown vent. A vent shall not be installed within two pipe diameters of the trap weir.

SECTION 907 INDIVIDUAL VENT

907.1 Individual vent permitted. Each trap and trapped fixture is permitted to be provided with an individual vent. The individual vent shall connect to the fixture drain of the trap or trapped fixture being vented.

SECTION 908 COMMON VENT

908.1 Individual vent as common vent. An individual vent is permitted to vent two traps or trapped fixtures as a common vent. The traps or trapped fixtures being common vented shall be located on the same floor level.

908.2 Connection at the same level. Where the fixture drains being common vented connect at the same level, the vent connection shall be at the interconnection of the fixture drains or downstream of the interconnection.

908.3 Connection at different levels. Where the fixture drains connect at different levels, the vent shall connect as a vertical extension of the vertical drain. The vertical drain pipe connecting the two fixture drains shall be considered the vent for the

lower fixture drain, and shall be sized in accordance with Table 908.3. The upper fixture shall not be a water closet.

TABLE 908.3 COMMON VENT SIZES

PIPE SIZE (inches)	MAXIMUM DISCHARGE FROM UPPER FIXTURE DRAIN (dfu)
11/2	1
2	4
$2^{1}/_{2}$ to 3	6

For SI: 1 inch = 25.4 mm.

SECTION 909 WET VENTING

909.1 Wet vent permitted. Any combination of <u>fixtures located</u> on the same floor level is permitted to be vented by a wet vent. The wet vent shall be considered the vent for the fixtures and shall extend from the connection of the dry vent along the direction of the flow in the drain pipe to the most downstream fixture drain connection to the horizontal branch <u>drain</u>. A residential clothes washer drain line shall not be used as a wet vent.

909.1.1 Vertical wet vent. Any combination of <u>fixtures located</u> on the same floor level is permitted to be vented by a vertical wet vent. The vertical wet vent shall extend from the connection to the dry vent down to the lowest fixture drain connection. Each fixture shall connect independently to the vertical wet vent. Water closet drains shall connect at the same elevation. Other fixture drains shall connect above or at the same elevation as the water closet fixture drains. The dry vent connection to the vertical wet vent shall be an individual or common vent serving one or two fixtures.

909.2 Vent connection. The dry vent connection to the wet vent shall be an individual vent or common <u>vent. The</u> dry vent shall be sized based on the largest required diameter of pipe within the wet vent system served by the dry vent.

909.3 Size. The wet vent shall be of a minimum size as specified in Table 909.3, based on the fixture unit discharge to the wet vent.

TABLE 909.3 WET VENT SIZE

WET VENT PIPE SIZE (inches)	DRAINAGE FIXTURE UNIT LOAD (dfu)
11/2	1
2	4
21/2	6
3	12

For SI: 1 inch = 25.4 mm.

909.4 Multistory bathroom groups. On the lower floors of a multistory building, the waste pipe from one or two lavatories may be used as a wet vent for one or two bathtubs or showers provided that:

- 1. The wet vent and its extension to the vent stack is not less than 2-inch (51 mm) diameter;
- Each water closet below the top floor is individually back vented; and
- 3. The vent stack is sized in accordance with Table 909.4.

Exception: In multistory bathroom groups (does not apply to one- and two-family dwellings), wet vented in accordance with Section 909.4 the water closets below the top floor need not be individually vented if a 2-inch (51 mm) wet vent connects downstream of the water closet.

TABLE 909.4 SIZE OF VENT STACK

NUMBER OF WET VENTED FIXTURES	DIAMETER OF VENT STACKS (IN.)
1 or 2 bathtubs or showers	2
3 to 5 bathtubs or showers	$2^{1}l_{2}$
6 to 9 bathtubs or showers	3
10 to 16 bathtubs or showers	4

For SI: 1 inch = 25.4 mm.

SECTION 910 WASTE STACK VENT

910.1 Waste stack vent permitted. A waste stack shall be considered a vent for all of the fixtures discharging to the stack where installed in accordance with the requirements of this section.

910.2 Stack installation. The waste stack shall be vertical, and both horizontal and vertical offsets shall be prohibited. Every fixture drain shall connect separately to the waste stack. The stack shall not receive the discharge of water closets or urinals.

910.3 Stack vent. A stack vent shall be provided for the waste stack. The size of the stack vent shall be equal to the size of the waste stack. Offsets shall be permitted in the stack vent and shall be located at least 6 inches (152 mm) above the flood level of the highest fixture, and shall be in accordance with Section 905.2.

910.4 Waste stack size. The waste stack shall be sized based on the total discharge to the stack and the discharge within a branch interval in accordance with Table 910.4. The waste stack shall be the same size throughout its length.

TABLE 910.4	
WASTE STACK VENT	SIZE

	MAXIMUM NUMBER OF DRAINAGE FIXTURE UNITS (dfu)							
STACK SIZE (inches)	Total discharge into one branch interval	Total discharge for stack						
11/2	1	2						
2	2	4						
21/2	No limit	8						
3	No limit	24						
4	No limit	50						
5	No limit	75						
6	No limit	100						

For SI: 1 inch = 25.4 mm.

SECTION 911 CIRCUIT VENTING

- **911.1** Circuit vent permitted. A maximum of eight fixtures connected to a horizontal branch drain shall be permitted to be circuit vented. Each fixture drain shall connect horizontally to the horizontal branch being circuit vented. The horizontal branch drain shall be classified as a vent from the most downstream fixture drain connection to the most upstream fixture drain connection to the horizontal branch.
 - **911.1.1** Multiple circuit-vented branches. Circuit-vented horizontal branch drains are permitted to be connected together. Each group of a maximum of eight fixtures shall be considered a separate circuit vent and shall conform to the requirements of this section.
- **911.2 Vent connection.** The circuit vent connection shall be located between the two most upstream fixture drains. The vent shall connect to the horizontal branch and shall be installed in accordance with Section 905. The circuit vent pipe shall not receive the discharge of any soil or waste.
- **911.3** Slope and size of horizontal branch. The maximum slope of the vent section of the horizontal branch drain shall be one unit vertical in 12 units horizontal (8-percent slope). The entire length of the vent section of the horizontal branch drain shall be sized for the total drainage discharge to the branch.
 - **911.3.1 Size of multiple circuit vent.** Each separate circuit-vented horizontal branch that is interconnected shall be sized independently in accordance with Section 911.3. The downstream circuit-vented horizontal branch shall be sized for the total discharge into the branch, including the upstream branches and the fixtures within the branch.
- **911.4 Relief vent.** A relief vent shall be provided for circuitvented horizontal branches receiving the discharge of four or more water closets and connecting to a drainage stack that receives the discharge of soil or waste from upper horizontal branches.
 - **911.4.1 Connection and installation.** The relief vent shall connect to the horizontal branch drain between the stack

- and the most downstream fixture drain of the circuit vent. The relief vent shall be installed in accordance with Section 905
- **911.4.2 Fixture drain or branch.** The relief vent is permitted to be a fixture drain or fixture branch for fixtures located within the same branch interval as the circuit-vented horizontal branch. The maximum discharge to a relief vent shall be four fixture units.
- **911.5** Additional fixtures. Fixtures, other than the circuit-vented fixtures, are permitted to discharge to the horizontal branch drain. Such fixtures shall be located on the same floor as the circuit-vented fixtures and shall be either individually or common vented.

SECTION 912 COMBINATION WASTE AND VENT SYSTEM

912.1 Approval. Plans and specifications for each combination waste and vent system shall be submitted to the plumbing official, and approval shall be obtained before any installation is started.

912.2 Limits.

- 912.2.1 A combination waste and vent system is limited to sinks, dishwashers, floor sinks, indirect waste receptors, floor drains or similar applications where the fixtures are not adjacent to walls or partitions. It consists of the installation of waste piping in which the trap of the fixture is not individually vented.
- 912.2.2 Caution must be exercised to exclude appurtenances delivering large quantities of water or sewage such as pumps, etc., in a combination waste and vent system in order that adequate venting will be maintained.
- **912.3. Dishwashers.** Dishwashers and scullery sinks in commercial buildings shall drain through a grease interceptor sized in accordance with this code and they shall discharge into a floor sink through a minimum air gap.

912.4. <u>General design.</u>

- 912.4.1 Every waste pipe and trap in this system shall be at least two pipe sizes larger than the size required in Chapter 7, and at least two pipe sizes larger than any fixture tailpiece or connection, except that when "P" traps are installed above the floor, the "P" trap and horizontal fixture drain need not meet this requirement. The vertical waste pipe two sizes larger than the fixture outlet connection shall be extended above the floor to normal roughing height, and a cleanout shall be installed in top of the connecting waste tee. The fixture drain length shall be limited by Table 906.1. Floor sinks shall be connected through a running trap two pipe sizes larger than the sink outlet. Floor sink and waste piping from the floor sink to the trap shall be sized for the total fixture units draining thereto, based on Table 709.1, but in no case shall the line be less than 2-inch (51 mm) soil pipe when piping is underground.
- 912.4.2 A vent shall be provided at the upstream end of each branch, washed over or under by the last fixture on the branch. No vent shall take off from the horizontal waste branch at an angle of less than 45 degrees (0.785 rad) from

the horizontal unless washed by a fixture. A minimum size vent shall be located at all points where branches intersect. A vent shall be located downstream from all fixtures in the system, in addition to the upstream vent, separating this system from all other systems in the building. No fixtures other than those permitted in Section 912.2 shall discharge into any branch or portion of this system.

912.4.3 Caution shall be used in the design of the system to assure that the vertical distance from fixture or drain outlet to trap weir does not exceed 24 inches (610 mm). Long runs shall be provided with additional relief vents located at intervals of not more than 100 feet (30.5 m) to equalize pressure in the system.

912.5 Size of vents. The size of vents shall be in accordance with requirements of Section 916.1 and Table 916.1, but the diameter shall be not less than one-half of the diameter of the waste pipe served.

912.6 Receptor drain size. Indirect waste receptors shall be sized for the fixture units draining thereto, regardless of other requirements of this code.

SECTION 913 ISLAND FIXTURE VENTING

913.1 Limitation. Island fixture venting shall not be permitted for fixtures other than sinks and lavatories. Residential <u>type</u> kitchen sinks with a dishwasher waste connection, a food waste grinder, or both, in combination with the kitchen sink waste, shall be permitted to be vented in accordance with this section.

913.2 Vent connection. The island fixture vent shall connect to the fixture drain as required for an individual or common vent. The vent shall rise vertically to above the drainage outlet of the fixture being vented before offsetting horizontally or vertically downward. For multiple island fixture vents, the vent or branch vent shall extend to a minimum of 6 inches (152 mm) above the highest island fixture being vented before connecting to the outside vent terminal.

913.3 Vent installation below the fixture flood level rim. The vent located below the flood level rim of the fixture being vented shall be installed as required for drainage piping in accordance with Chapter 7, except for sizing. The vent shall be sized in accordance with Section 916.2. The lowest point of the

TABLE 916.1
SIZE AND DEVELOPED LENGTH OF STACK VENTS AND VENT STACKS

DIAMETER OF SOIL OR WASTE STACK	TOTAL FIXTURE UNITS BEING	MAXIMUM DEVELOPED LENGTH OF VENT (feet) ^a DIAMETER OF VENT (inches)													
(inches)	VENTED (dfu)	1 ¹ / ₄	1 ¹ / ₂	2	2 ¹ / ₂	3	4	5	6	8	10	12			
11/4	2	30													
$1^{1}/_{2}$	8	50	150	_	_	_	_	_	_	_	_	l —			
$1^{1}/_{2}$	10	30	100												
2	12	30	75	200											
2	20	26	50	150		_		_	_	_	_	_			
21/2	42		30	100	300										
3	10		42	150	360	1,040									
3	21		32	110	270	810				_					
3	53		27	94	230	680									
3	102		25	86	210	620									
4	43	_		35	85	250	980	_	_	_	_	_			
4	140			27	65	200	750								
4	320			23	55	170	640								
4	540	_	_	21	50	150	580		_	_	_	_			
5	190				28	82	320	990							
5	490				21	63	250	760							
5	940	_	_		18	53	210	670		_		_			
5	1,400				16	49	190	590							
6	500					33	130	400	1,000						
6	1,100	_	_	_	_	26	100	310	780	_	_	_			
6	2,000					22	84	260	660						
6	2,900					20	77	240	600						
8	1,800	_	_	_	_		31	95	240	940	_	_			
8	3,400						24	73	190	720					

(continued)

	SIZE AND	DEVELO	PED LEI	NG TH OF	- STACK	VENIS	AND VEN	II STACI	KS			
DIAMETER OF SOIL OR	TOTAL FIXTURE UNITS BEING	MAXIMUM DEVELOPED LENGTH OF VENT (feet) ^a DIAMETER OF VENT (inches)										
WASTE STACK (inches)	VENTED (dfu)	1 ¹ / ₄	1 ¹ / ₂	2	21/2	3	4	5	6	8	10	12
8	5,600						20	62	160	610		
8	7,600	_	_	_	_	_	18	56	140	560		—
10	4,000							31	78	310	960	
10	7,200							24	60	240	740	
10	11,000	_	_	_	_	_		20	51	200	630	_
10	15,000							18	46	180	570	
12	7,300								31	120	380	940
12	13,000	_	_	_	_	_	_	_	24	94	300	720
12	20,000								20	79	250	610
12	26,000								18	72	230	500
15	15,000	_	_	_	_	_	_	_		40	130	310
15	25,000									31	96	240
15	38,000									26	81	200
15	50,000	-	_	_	_	_	_	_	_	24	74	180

TABLE 916.1—continued
SIZE AND DEVELOPED LENGTH OF STACK VENTS AND VENT STACKS

For SI: 1 inch = 25.4 mm, 1 foot = 304.8 mm.

a. The developed length shall be measured from the vent connection to the open air.

island fixture vent shall connect full size to the drainage system. The connection shall be to a vertical drain pipe or to the top half of a horizontal drain pipe. Cleanouts shall be provided in the island fixture vent to permit rodding of all vent piping located below the flood level rim of the fixtures. Rodding in both directions shall be permitted through a cleanout.

SECTION 914 RELIEF VENTS—STACKS OF MORE THAN 10 BRANCH INTERVALS

914.1 Where required. Soil and waste stacks in buildings having more than 10 branch intervals shall be provided with a relief vent at each tenth interval installed, beginning with the top floor.

914.2 Size and connection. The size of the relief vent shall be equal to the size of the vent stack to which it connects. The lower end of each relief vent shall connect to the soil or waste stack through a wye below the horizontal branch serving the floor, and the upper end shall connect to the vent stack through a wye not less than 3 feet (914 mm) above the floor.

SECTION 915 VENTS FOR STACK OFFSETS

915.1 Vent for horizontal offset of drainage stack. Horizontal offsets of drainage stacks shall be vented where five or more branch intervals are located above the offset. The offset shall be vented by venting the upper section of the drainage stack and the lower section of the drainage stack.

915.2 Upper section. The upper section of the drainage stack shall be vented as a separate stack with a vent stack connection

installed in accordance with Section 903.4. The offset shall be considered the base of the stack.

915.3 Lower section. The lower section of the drainage stack shall be vented by a yoke vent connecting between the offset and the next lower horizontal branch. The yoke vent connection shall be permitted to be a vertical extension of the drainage stack. The size of the yoke vent and connection shall be a minimum of the size required for the vent stack of the drainage stack.

SECTION 916 VENT PIPE SIZING

916.1 Size of stack vents and vent stacks. The minimum required diameter of stack vents and vent stacks shall be determined from the developed length and the total of drainage fixture units connected thereto in accordance with Table 916.1, but in no case shall the diameter be less than one-half the diameter of the drain served or less than 11/4 inches (32 mm).

916.2 Vents other than stack vents or vent stacks. The diameter of individual vents, branch vents, circuit vents and relief vents shall be at least one-half the required diameter of the drain served. The required size of the drain shall be determined in accordance with Table 710.1(2). Vent pipes shall not be less than $1^{1}/_{4}$ inches (32 mm) in diameter. Vents exceeding 40 feet (12 192 mm) in developed length shall be increased by one nominal pipe size for the entire developed length of the vent pipe. Relief vents for soil and waste stacks in buildings having more than 10 branch intervals shall be sized in accordance with Section 914.2.

916.3 Developed length. The developed length of individual, branch, circuit and relief vents shall be measured from the far-

	MAXIMUM DEVELOPED LENGTH OF VENT (feet) ^a										
DISCHARGE CAPACITY OF PUMP			Diameter of	vent (inches)							
(gpm)	1 ¹ / ₄	1 ¹ / ₂	2	2 ¹ / ₂	3	4					
10	No limit ^b	No limit	No limit	No limit	No limit	No limit					
20	270	No limit	No limit	No limit	No limit	No limit					
40	72	160	No limit	No limit	No limit	No limit					
60	31	75	270	No limit	No limit	No limit					
80	16	41	150	380	No limit	No limit					
100	10°	25	97	250	No limit	No limit					
150	Not permitted	10°	44	110	370	No limit					
200	Not permitted	Not permitted	20	60	210	No limit					
250	Not permitted	Not permitted	10	36	132	No limit					
300	Not permitted	Not permitted	10°	22	88	380					
400	Not permitted	Not permitted	Not permitted	10°	44	210					
500	Not permitted	Not permitted	Not permitted	Not permitted	24	130					

TABLE 916.5.1 SIZE AND LENGTH OF SUMP VENTS

For SI: 1 inch = 25.4 mm, 1 foot = 304.8 mm, 1 gallon per minute = 3.785 L/m.

- b. Actual values greater than 500 feet.
- c. Less than 10 feet.

thest point of vent connection to the drainage system to the point of connection to the vent stack, stack vent or termination outside of the building.

916.4 Multiple branch vents. Where multiple branch vents are connected to a common branch vent, the common branch vent shall be sized in accordance with this section based on the size of the common horizontal drainage branch that is or would be required to serve the total drainage fixture unit (dfu) load being vented.

916.4.1 Branch vents exceeding 40 feet in developed length. Branch vents exceeding 40 feet (12 192 mm) in developed length shall be increased by one nominal size for the entire developed length of the vent pipe.

916.5 Sump vents. Sump vent sizes shall be determined in accordance with Sections 916.5.1 and 916.5.2.

916.5.1 Sewage pumps and sewage ejectors other than pneumatic. Drainage piping below sewer level shall be vented in a similar manner to that of a gravity system. Building sump vent sizes for sumps with sewage pumps or sewage ejectors, other than pneumatic, shall be determined in accordance with Table 916.5.1.

916.5.2 Pneumatic sewage ejectors. The air pressure relief pipe from a pneumatic sewage ejector shall be connected to an independent vent stack terminating as required for vent extensions through the roof. The relief pipe shall be sized to relieve air pressure inside the ejector to atmospheric pressure, but shall not be less than $1^{1}/_{4}$ inches (32 mm) in size.

SECTION 917 AIR ADMITTANCE VALVES

917.1 General. Vent systems utilizing air admittance valves shall comply with this section. Individual- and branch-type air admittance valves shall conform to ASSE 1051.

917.2 Installation. The valves shall be installed in accordance with the requirements of this section and the manufacturer's installation instructions. Air admittance valves shall be installed after the DWV testing required by Section 312.2 or 312.3 has been performed.

917.3 Where permitted. Individual, branch and circuit vents shall be permitted to terminate with a connection to an air admittance valve. The air admittance valve shall only vent fixtures that are on the same floor level and connect to a horizontal branch drain. The horizontal branch drain shall conform to Section 917.3.1 or Section 917.3.2.

917.3.1 Location of branch. The horizontal branch drain shall connect to the drainage stack or building drain a maximum of four branch intervals from the top of the stack.

917.3.2 Relief vent. The horizontal branch shall be provided with a relief vent that shall connect to a vent stack, or stack vent, or extend outdoors to the open air. The relief vent shall connect to the horizontal branch drain between the stack or building drain and the most downstream fixture drain connected to the horizontal branch drain. The relief vent shall be sized in accordance with Section 916.2 and installed in accordance with Section 905. The relief

a. Developed length plus an appropriate allowance for entrance losses and friction due to fittings, changes in direction and diameter. Suggested allowances shall be obtained from NSB Monograph 31 or other approved sources. An allowance of 50 percent of the developed length shall be assumed if a more precise value is not available

vent shall be permitted to serve as the vent for other fixtures.

917.4 Location. The air admittance valve shall be located a minimum of 4 inches (102 mm) above the horizontal branch drain or fixture drain being vented. The air admittance valve shall be located within the maximum developed length permitted for the vent. The air admittance valve shall be installed a minimum of 6 inches (152 mm) above insulation materials.

917.5 Access and ventilation. Access shall be provided to all air admittance valves. The valve shall be located within a ventilated space that allows air to enter the valve.

917.6 Size. The air admittance valve shall be rated in accordance with the standard for the size of the vent to which the valve is connected.

917.7 Vent required. Within each plumbing system, a minimum of one stack vent or vent stack shall extend outdoors to the open air.

917.8 Prohibited installations. Air admittance valves shall not be installed in nonneutralized special waste systems as described in Chapter 8. Valves shall not be located in spaces utilized as supply or return air plenums.

SECTION 918 ENGINEERED VENT SYSTEMS

Deleted.

TABLE 918.2

MINIMUM DIAMETER AND MAXIMUM LENGTH OF INDIVIDUAL BRANCH FIXTURE VENTS AND INDIVIDUAL FIXTURE HEADER VENTS FOR SMOOTH PIPES

Deleted.

SECTION 919 COMPUTERIZED VENT DESIGN

Deleted.

SECTION 920 SINGLE STACK PLUMBING SYSTEMS (SOVENT)

Design and installation shall be in accordance with design criteria contained in the Copper Development Association (CDA) Handbook No. 802. Materials shall meet standards and specifications listed in Tables 702.1 and 702.4 for drain, waste and vent pipe and fittings.